

FRC-Q
FRC-F

VVVF Controller

for

Elevators

(upon Software 18.050.04)

Contents

1	Important Notes	7
1.1	Safety Tips	7
1.2	Retrofitting old systems	7
1.3	Installation of the VVVF controller.....	7
1.4	See to sufficient ventilation of the cabinet	8
1.5	Connection of contactor coils.....	8
1.6	Contactor mounting plate.....	8
1.7	Earthing	8
1.8	Earth-leakage circuit-breaker	8
1.9	Motor protectio by ptc-thermistor	8
1.10	Motor protection switch	9
1.11	Group control.....	9
1.12	Reactive current compensation	9
1.13	Warranty	9
2	Standards	10
3	Technical Specification	12
4	Installation.....	20
4.1	Shaft installation.....	20
4.1.1	Deceleration distance / leveling switches.....	20
4.1.2	Direct landing	20
4.1.2.1	Landing without reference signal	20
4.1.2.2	Landing with reference signal	20
4.2	Connection of VVVF controller	22
4.2.1	Power connections.....	22
4.2.1.1	Protective conductor	22
4.2.1.2	Connection to power supply.....	22
4.2.1.3	Fans	22
4.2.1.4	Motor phases	22
4.2.1.5	Braking resistor	22
4.2.2	Low-voltage connections.....	23
4.2.2.1	Encoder	23
4.2.2.1.1	Square wave encoder.....	23
4.2.2.1.2	Sine encoder	23
4.2.2.2	Drive command inputs	24
4.2.2.2.1	General.....	24
4.2.2.2.2	Overview.....	24
4.2.2.2.3	Setting the direction.....	24
4.2.2.2.4	Control via floating contacts, internal control voltage	25
4.2.2.2.5	Control via floating contacts, external control voltage	25
4.2.2.2.6	Signal procedure at normal operation (example: up-travel at V4)	26
4.2.2.2.7	Signal procedure at inspection	28
4.2.2.2.8	Signal procedure for levelling operation	28
4.2.2.3	Digital inputs.....	30
4.2.2.4	Motor PTC input	30
4.2.2.5	Relay outputs	30
4.2.2.6	Incremental encoder signals for shaft copying of the elevator control	30
4.2.2.7	Digital outputs	31
4.2.2.8	RS-485 interface / DCP mode	31
5	Commissioning.....	33
5.1	Use of the VVVF controller	33
5.1.1	Control elements	33
5.1.2	Entering parameter values	33
5.1.3	Navigation in the menu.....	34
5.2	Factory settings, parameter overview.....	35

5.3	Menu overview.....	37
5.4	Switching on the power supply	39
5.5	Adaptation of the controller parameters to the system.....	39
5.6	First travel operation.....	40
5.7	The Menu.....	41
5.7.1	Selection of units	41
5.7.2	Error messages.....	41
5.7.3	Acknowledging faults.....	41
5.7.3.1	Manual acknowledgement using the unit's keyboard	41
5.7.3.2	External acknowledgement by a +24V signal	41
5.7.3.3	Acknowledgement by the unit itself by auto-fault reset	42
5.7.4	Setting – programming the converter.....	42
5.7.4.1	Setting speeds	42
5.7.4.2	Setting the starting behaviour.....	44
5.7.4.3	Setting the times/distances	44
5.7.4.4	Setting the speed controller	46
5.7.4.5	Adapting the unit to the system.....	47
5.7.5	Display/Scanning operating variables	48
5.7.5.1	Display of actual and set values.....	48
5.7.5.1.1	Speed	48
5.7.5.1.2	Motor current and torque.....	48
5.7.5.1.3	Other variables	48
5.7.5.1.4	Maximum value storage	49
5.7.5.1.5	Bar graph display of deviation between required and actual speeds	49
5.7.5.2	Display of inputs/outputs	49
5.7.5.2.1	Drive commands	49
5.7.5.2.2	Digital inputs	49
5.7.5.2.3	Digital outputs.....	49
5.7.5.2.4	Relay outputs.....	50
5.7.5.3	Display of errorstack	50
5.7.5.4	Display of statistical data.....	50
5.7.5.5	Display of current errors.....	51
5.7.6	System settings.....	51
5.7.6.1	Unit password protection.....	51
5.7.6.2	Setting the language	52
5.7.6.3	Units - rpm or m/sec.....	52
5.7.6.4	Unit operating modes.....	53
5.7.7	Information menu	53
5.7.7.1	Hardware.....	53
5.7.7.2	Software	53
5.7.7.3	Operating mode	54
5.7.8	Extended menus	54
5.7.8.1	Synchronous machine.....	55
5.7.8.2	Open-Loop Mode	55
5.7.8.3	Extended general settings.....	55
5.7.8.4	Extended drive curve settings.....	55
5.7.8.4.1	Floor to floor correction.....	56
5.7.8.4.2	Set value - ramp shape	56
5.7.8.4.3	Speed transitions.....	56
5.7.8.4.4	Direct landing with reference signal.....	57
5.7.8.5	Extended control settings.....	58
5.7.8.6	Configuring fault behaviour	59
5.7.8.7	Selection of works-setting	60
5.7.8.8	Configuration of inputs and outputs	60
5.7.8.9	Encoder	60
5.7.8.10	Digital inputs.....	60
5.7.8.11	Drive Commands	61
5.7.8.11.1	Encoding.....	61
5.7.8.11.2	Configuration of direction signals	61
5.7.8.12	Further supervisions.....	61
5.7.8.13	Operating with DCP-Interface	62
5.7.8.13.1	General information on DCP operation	62
5.7.8.13.2	Operating modes.....	62


5.7.8.13.3	Wiring	62
5.7.8.13.4	Activation of the serial converter control (DCP mode)	62
5.7.8.13.5	Connection monitoring.....	63
5.7.8.13.6	Diagnostics menu	63
5.7.8.13.7	Setting the S- curve at DCP02	63
5.7.8.14	Extended Error menu	64
5.7.8.15	Converter-specific settings.....	64
5.7.8.16	Loosening the cabin from the safety catch, travel at increased break-away torque	64
5.7.8.17	Trace/Debug	64
5.8	Use with synchronous machines / gearless.....	65
5.8.1	Parameterization	65
5.8.1.1	Automatic setup by using pre-defined data records.....	65
5.8.1.2	Manual setting of the parameters	65
5.8.2	Calibration - determination of angle offset	66
5.8.2.1	Use with absolute value encoder ECN1313 from Heidenhain	66
5.8.2.1.1	Calibration	66
5.8.2.1.2	Checking the rotational sense assignment.....	66
5.8.2.2	Use with sin/cos encoders with zero pulse	67
5.9	Open-Loop Mode.....	67
5.9.1	Open-Loop 1 (F/U control with slip compensation)	67
5.9.1.1	Parameter overview	67
5.9.1.2	Setup of converter.....	68
5.9.1.2.1	Activating the operating mode	68
5.9.1.2.2	Automatic measurement of motor parameters.....	68
5.9.1.2.3	Setup of dynamics	68
5.9.1.2.4	Adjusting the speed accuracy.....	69
5.9.1.2.5	Static load compensation	69
5.9.2	Open-Loop 2 (F/U control with characteristic adjustment).....	69
5.9.2.1	Parameter overview	69
5.9.2.2	Setup of converter.....	70
5.9.2.2.1	Activating the operating mode	70
5.9.2.2.2	Automatic measurement of motor parameters.....	70
5.9.2.2.3	Setup of dynamics	70
5.9.2.2.4	Adjusting the speed accuracy.....	71
5.9.2.2.5	Static load compensation	71
5.10	Emergency current evacuation with UPS.....	72
5.10.1	General.....	72
5.10.2	Wiring.....	72
5.10.3	Dimensioning of UPS.....	73
5.10.4	Particularities of the VVVF-controller during evacuation.....	74
5.11	Remote data transmission per modem	75
5.11.1	General.....	75
5.11.2	Modem on laptop/PC.....	75
5.11.3	Modem on FRC-Q.....	75
5.11.3.1	Configuration of modem on the converter.....	75
6	Service and maintenance.....	76
7	FRC-Q with integrated drive contactors	77
7.1	General	77
7.2	Technical Specification	77
7.2.1	Housing	77
7.2.2	Fastening the cables	79
7.2.3	Wiring.....	79
8	Troubleshooting.....	80
8.1	Error messages at the converter	80
8.1.1	Encoder polarity	80
8.1.2	No start-up.....	80
8.1.3	Overspeed.....	80
8.1.4	Control Deviation	80
8.1.5	Overcurrent	80
8.1.6	Overvoltage DC.....	81
8.1.7	Undervoltage DC.....	81

8.1.8	Motor adaptation	81
8.1.9	Temperature KK. (Overtemperature)	81
8.1.10	DCP error	81
8.1.11	Runtime error	81
8.1.12	Contactore error	81
8.1.13	Power unit	82
8.1.14	Calibration	82
8.1.15	Earth fault	82
8.1.16	Motor overload	82
8.1.17	Phase failure	82
8.1.18	Referencing	82
8.1.19	SSC Error	83
8.1.20	Sine controller	83
8.2	Warnings at converter	83
8.2.1	Direction signals	83
8.2.2	Temperature	83
8.2.3	Motor data o.k. ?	83
8.2.4	Version PowerCtr	83

Pictograms



Important note! Comply in any case. Non-compliance may result in malfunction or damage.



Danger due to electrical voltage! Danger to life and limb!



Useful tip.

1 Important Notes



1.1 Safety Tips

- Depending on the class of their isolation, the surface of VVVF controllers can possibly be in circuit, bare or hot.
- Unadmitted removal of parts of the casing, improper use, wrong installation or operation are dangerous to life, injurious to health or can cause damages.
- Every work in connection with transport, installation and initiation as well as servicing is to be executed by competent persons labour.
- Skilled labour according to this basic safety tip includes field personnel familiar with the mounting, installation, initiation and operation of this product and qualified for this work.
- VVVF controllers are components of electric devices or machines. Their initiation, i.e. start of the destined operation, is subject to keeping to the EMC-regulations (89/336/EC).
- Technical specifications and information concerning conditions of connecting are to be read from the type label and the documentation and are by all means to be adhered to.



1.2 Retrofitting old systems

Before retrofitting a VVVF controller in an existing elevator ask your motor supplier, whether the isolation of the motor-winding is suitable for VVVF controller-operation.

If the motor originally has not been conceived for VVVF controller-operation, we recommend, however, to install an external inductor in addition to the integrated one. If you are not sure, please contact us. We will be pleased to advise you.



1.3 Installation of the VVVF controller

Please pay your special attention to the signal lines and power lines that they do not cross over each other nor lie in parallel in a mutual cable duct. For EMC-reasons, it is recommendable to separate them to prevent interference effects.

Appropriate **terminal covers with strain relief** are available from us for using the unit outside the control cabinet. In our VVVF with integrated contactors these are already included.

Install the braking resistor **outside** the cabinet, in order to avoid unnecessary heat dissipation to the electronic devices inside the cabinet.

Important note !

Due to the heat dissipation the brake resistor should always be fixed on non-flammable bases. For proper ventilation there should be at least 20 cm space above and below the brake resistor. If there are inflammable materials in the closer area, there should be a distance of 50 cm between the brake resistor and these materials.

This also applies to the contactor device with integrated brake resistor.



1.4 See to sufficient ventilation of the cabinet

Above and below the VVVF controller, leave space of at least 10 cm height, in order to provide sufficient ventilation.

Moreover, use a enclosure with perforated floor and ceiling, most probably your supplier of enclosures will offer appropriate pre-fabricated metal sheets. This will support ventilation and prevent thermal failure of electronic parts even in midsummer. If necessary, **forced ventilation** must be provided in the enclosure.

Temperature in the enclosure must be kept below 50°C at any operational situation. Failure or malfunction of the electronics will not be under warranty, if this temperature is exceeded.

For further information on power loss of the devices, please refer to **Section 3**.



1.5 Connection of contactor coils

To avoid inductive voltage peaks during contactor operation, they should be provided either with varistors or RC elements.

1.6 Contactor mounting plate

- The mounting plate must be well grounded
- In the case of a very high unit performance where contactor operation may cause significant mechanical vibration in the enclosure, the contactors should be equipped with rubber-metal vibration dampers.



1.7 Earthing

- On principle, use screened cables and lines only, for every connection to outside of the enclosure, i.e.:
 - from enclosure to motor
 - from enclosure to encoder
 - from enclosure to braking resistor
- The cable from the encoder is to be screened up to the plug in the VVVF controller. To earth the screening of the encoder cable, connect it to a cable clip of the VVVF controller.

1.8 Earth-leakage circuit-breaker

- The elevator must not be operated via an earth-leakage circuit-breaker, as the leakage current of the interference suppression capacitors contained in the VVVF controller and the interference suppression filter would operate this circuit-breaker. Should it nevertheless be inevitable to install an earth-leakage circuit breaker due to a special situation concerning the elevator, only use circuit-breakers admitted to VVVF controller-operation.

1.9 Motor protectio by ptc-thermistor


An element evaluating the ptc-thermistor is integrated in the VVVF controller.

1.10 Motor protection switch

Motor protection switches on principle do not suit a VVVF-controlled elevator drive and must therefore not be applied.

1.11 Group control

In cases where more than one drive is connected to the mains supply, we recommend that the drives were additionally isolated by three-phase commutation inductors (=line reactors).



1.12 Reactive current compensation

If capacitors compensating reactive current were connected directly to the motor connectors, they would destroy the VVVF controller, as due to the high switching frequency of the transistors a would-be short circuit would be created.

Reactive current compensation, if at all, is to be executed at the mains connection of the building, but never in the machine room.

1.13 Warranty

As for warranty please refer to our General Conditions. Demands going beyond these conditions are subject to a special agreement.

2 Standards

VVVF controllers FRC-Q/FRC-F comply with the following national and international standards and regulations:

CE - mark	European declaration of conformity
DIN EN 12015	Standards and regulations for the product family of elevators, escalators and passenger conveyors. EMC : emitted interference
DIN EN 12016	Standards and regulations for the product family of elevators, escalators and passenger conveyors. EMC- interference immunity
DIN IEC 60038	Standardised voltages
DIN EN 81 Part 1	Safety rules for the design and installation of elevators for persons and goods as well as small goods elevators Electrically operated elevators
DIN VDE 50178	Electrical power installations with electronic items
DIN EN 60439 Part 1	Control gear assemblies low-voltage control gear assemblies
DIN EN ISO 9001	Quality management, development, production, assembly and service

To comply with the relevant EMC-regulations, the following prerequisites are required:

Outside the cabinet, only screened cables and lines are to be used (except for mains supply line).



**Certificate of Conformity according to
EC-EMC-Directive 89/336/EWG**

A sample of product as detailed below has been tested and found to be in conformity with the EMC-regulations of the directive 89/336/EWG in all points.

Detailed information is shown in the EMC-test reports:

FRC-F1...F4: 28.001.01, 28.002.01, 28.003.01, 28.015.01
FRC-F5...F7: 28.013.01, 28.014.01, , 28.016.01

Model / Type: **FRC-F1...F7**

Identification: Electronic frequency inverter for elevator drives

Applied Harmonized Regulations:

**DIN EN 61000-6-3: August 2002
DIN EN 61000-6-2: August 2002**

28.10.2003

.....
Date

.....
Manufacturer-Signature

Writer: MM/28.10.2003
Adresse: Tannenstraße 11 · 74229 Oedheim
Telefon: +49 (7136) 20041-42 · Fax: +49 (7136) 23282
Sitz Oedheim

File: FRC-F_01E.SDW
AG Heilbronn HRB 3509
Geschäftsführer:
Hans Dekan

Page : 1

3 Technical Specification

With every detail we refer to a 4-pole one-speed A.C. synchronous and asynchronous motors. Modifications subject to technological progress will be possible at any time without prior notice.

Supply voltage (L1-L2-L3) :

FRC-F1 – FRC-F7: 230 ... 400 V ± 10%, 50/60 Hz
 FRC-Q8 – FRC-Q11: 230 ... 400 V ± 20%, 50/60 Hz

Sizes :

VVVF Controller		Motor power	Heat dissipation
Type	I_N / I_{max} in A_{eff}	P_{shaft} in kW (with 400V supply)	in W
FRC-F1	8 / 16	approx. 4	170
FRC-F2	12 / 24	approx. 5,5	240
FRC-F3	16 / 32	approx. 7,5	300
FRC-F4	24 / 48	approx. 11	480
FRC-F5	32 / 64	approx. 15	660
FRC-F6	40 / 80	approx. 18,5	800
FRC-F7	48 / 96	approx. 22	1000
FRC-Q8	60 / 120	approx. 30	1200
FRC-Q9	75 / 150	approx. 37	1480
FRC-Q10	90 / 180	approx. 45	1800
FRC-Q11	110 / 208	approx. 55	2200

Range of supply : - VVVF controller including mains filter
 - Documentation

Accessories :

- Braking resistor
- Mains input inductor
- Mains output inductor
- Setting-software PowerControl for Windows
- Modem for remote data transmission



Note : At travel speeds of more than 1,6 m/s apply braking resistors with higher capacities !

Power supply to electronic module of VVVF controller :

The VVVF controller supplies itself from the DC link. No separate power supply required.

Drive commands :

Floating contacts from control unit, voltage supply either from VVVF controller or from control voltage (refer to 4.2.2.2).

Fault messages / Monitoring :

Status of the VVVF controller during operation is steadily monitored. Errors are indicated on the display in plain text and recorded in the error stack to enable an analysis. The collective fault signal relay **TÜ** drops out in the case of an error (see **Section 8.1**).

Monitoring of levelling speed - EÜ :

Gives the safety-relevant speed signal necessary for realising that the doors start opening already during levelling. Together with the door-zone monitoring in the control unit thus the safety regulations are fulfilled concerning the use of doors starting to open during slowing down.

Brake monitoring BÜ:

Digital signal (24V / 50mA) in case motor speed falls below a preset value.

Control of drive contactors ZS:

Relay for controlling the drive contactors.

Control of brake ZB:

Relay for controlling the brake.

Encoder :

Standard digital encoders with the following specification can be applied:

- square-wave encoder HTL, TTL - 2 x 500 to 2 x 4096 pulses enabling stepless variation, operation possible with (A, B) or 4 (A, -A, B, -B) signal tracks.
- sine-wave pulse encoder 2 x 500 to 2 x 2048 sine periods (**additional board required**).

Possible supply voltages : +5V / +15V / ±15V

Maximum power input : 150 mA

Maximum permitted speed: 3000 rpm square wave encoder with 500 to 4096 pulses per rev.
3000 rpm sine wave encoder with 1024 to 2048 pulses per rev.

Reversing :

Reversing is initiated electronically. No reversing contactor required. Desired phase-rotation is set by signals **RO** and **RU**.

Setting of the VVVF controller :

The VVVF controller can completely be set by means of the integrated display with keyboard. As an alternative, setting can be done by a (Laptop-) **PC under Windows**.

Communication with the PC is done via an interface RS-232.

Connection to control :

- 6 drive speeds V0, V1, V2, V3, V4, VN
- 2 direction signals RU, RO
- drive enable GS
- 4 relays TÛ, ZS, ZB, EÛ
- 2 digital outputs FRC ready, brake monitoring (24 V / 50 mA)
- 2 digital inputs +24V programmable (see **Section 5.7.8.8**)
- 1 digital input +24V emergency power mode (see **Section 5.10**)

Connection of PTC-thermistor:

Standard-PTC's, shut-off point at approx. 3 kΩ.

At VVVF's with integrated contactors a temperature-switch, that is fixed at the backside of the case, is connected in series for temperature supervision of the brake resistor. The temperature threshold-value is approx. 80 °C.


Principle of control :


Field-oriented vector control (closed loop)
 Frequency-voltage control (open loop)

Range of temperature : + 10 ... + 50 °C

Dimensions :

VVVF Controller	Dimensions in mm
<i>type</i>	<i>length x width x depth</i>
FRC-F1	358 x 330 x 200
FRC-F2	358 x 330 x 200
FRC-F3	358 x 330 x 200
FRC-F4	358 x 330 x 200
FRC-F5	385 x 330 x 221
FRC-F6	385 x 330 x 221
FRC-F7	537 x 330 x 221
FRC-Q8	725 x 545 x 306
FRC-Q9	725 x 545 x 306
FRC-Q10	765 x 625 x 314
FRC-Q11	765 x 625 x 314






Alle Abmessungen in mm
Gewicht: ca. 22 kg

All dimensions in mm
Weight: appr. 22 kg

Technische Änderungen vorbehalten

Specification subject to change without notice

FRC-F5/F6		DIN ISO 2768m	Maßstab 1:3	Version
			Zehngs.-Nr.: 5.588.31	
		Datum	Name	
		Bearb. 25.09.03	Müller	
		Gepr.		
		Norm		
			Abmessungen Dimensions	
			Datei: 5-588-31	Blatt 1
31	Tannenstr.11 D-74229 Oedheim			1 Bl.
Index	Rev.	Änd.Nr.	Freigabe	Name



Alle Abmessungen in mm
Gewicht: ca. 25 kg


All dimensions in mm
Weight: appr. 25 kg

Technische Änderungen vorbehalten

Specification subject to change without notice

FRC-F7		DIN ISO 2768m	Maßstab 1:3		Version
			Zchngs.-Nr.: 5.589.31		
			Datum	Name	
			25.09.03	Müller	
			Gepr.		
			Norm		
			Tannenstr. 11 D-74229 Oedheim		
31			Datei:		Blatt
Index	Rev.	Änd.Nr.	Freigabe	5-589-31	1 Bl.



Abmessungen Dimensions



Alle Abmessungen in mm
All dimensions in mm

Gewicht: ca. 57 kg
Weight: appr. 57 kg

FRC-Q8/9		DIN ISO 2768 m	Maßstab 1:4	Version
			Zchngs.-Nr.: 5.476.31	
			Außenabmessungen Dimensions	
		Datum	Name	
		Bearb. 17.08.01	Müller	
		Gepr.		
		Norm		
31				
Index	Rev.	Änd.Nr.	Freigabe	Name
			Tannenstr.11 D-74229 Oedheim	Datei: 5-476-31
				Blatt 1 1 Bl.



Alle Abmessungen in mm
All dimensions in mm

Gewicht: ca. _____ kg
Weight: appr. _____ kg

FRC-Q10/Q11		DIN ISO 2768m	Maßstab 1:5	Version
			5.508.31	
			Zchngs.-Nr.: 5.508.31	
		Datum	Name	Außenabmessungen Dimensions
		Bearb. 19.02.03	Müller	
		Gepr.		
		Norm		
		Tannenstr. 11 D-74229 Oedheim		Datei: 5-508-31.skd
31				Blatt 1
Index	Rev.	Änd.Nr.	Freigabe	Name

4 Installation

By all means, please pay attention to the notes given in Section 1!



Danger !

Never carry out electrical work at live systems. Before carrying out any work, disconnect the unit from power supply. After disconnection of the power supply, the DC link will still remain live for several minutes !

4.1 Shaft installation

4.1.1 Deceleration distance / leveling switches

Shut-off points for fast speed V4 and creep speed V0 are to be adjusted for up and down to exactly equivalent distances at every landing (see following table).

Levelling switches to be adjusted independently from V4 to approx. 5-8 cm ahead of flush landing level, exactly symmetrical from both directions.

Empirically, the following distances make sense, depending on the travel speed:

Travel speed	Disconnection distance	Length of inductor plate or magnet assembly
0,5 – 1,25 m/sec	approx. 5 cm	2 x 5 cm = 10 cm
1,5 – 2,5 m/sec	approx. 8 cm	2 x 8 cm = 16 cm

Note : In case of direct landing approach, V0-disconnection points are of course annulled.

4.1.2 Direct landing

4.1.2.1 Landing without reference signal

Only one disconnection point for high-speed (V4) is required. It can be set by parameter B (deceleration ramp). During the deceleration, a **position controller** is active which controls the position exactly.



Conditions for a perfect direct landing approach :

- Disconnection point for V4 is to be adjusted exactly identical at all landings in order to warrant a uniform stopping accuracy.
- The braking command from the control must be reproducible exactly !

Example : Running speed $v = 2 \text{ m/sec} = 2 \text{ mm/msec}$
 A deviation of **1 msec** would result in an inaccuracy of **2 mm** !

4.1.2.2 Landing with reference signal

Experience has shown that direct landing is hardly ever possible due to different parameters (slip, software runtimes, etc.) Most elevator control systems offer a signal which is activated at a definable distance from the leveling position (mostly in zone range). This signal can be used by the VVF controller to correct the deceleration ramp such that the exact leveling position is reached (see section 5.7.8.4.4)

Table of stopping distances:

v [m/sec]	Stopping distance [m]			
	a=-0,6 m/sec	a=-0,8 m/sec	a=-1 m/sec	a=-1,2 m/sec
0,5	0,76	0,71	0,68	0,65
0,6	0,91	0,84	0,79	0,76
0,7	1,08	0,98	0,92	0,87
0,8	1,26	1,13	1,05	1,00
0,9	1,47	1,30	1,20	1,13
1	1,68	1,48	1,35	1,27
1,1	1,92	1,67	1,52	1,41
1,2	2,17	1,87	1,69	1,57
1,3	2,44	2,09	1,88	1,73
1,4	2,72	2,32	2,07	1,91
1,5	3,03	2,56	2,28	2,09
1,6	3,34	2,81	2,49	2,28
1,7	3,68	3,08	2,72	2,47
1,8	4,03	3,36	2,95	2,68
1,9	4,40	3,65	3,20	2,89
2	4,78	3,95	3,45	3,12
2,1	5,19	4,27	3,72	3,35
2,2	5,60	4,60	3,99	3,59
2,3	6,04	4,94	4,28	3,83
2,4	6,49	5,29	4,57	4,09
2,5	6,96	5,66	4,88	4,35
2,6	7,44	6,04	5,19	4,63
2,7	7,95	6,43	5,52	4,91
2,8	8,46	6,83	5,85	5,20
2,9	9,00	7,25	6,20	5,49
3	9,55	7,68	6,55	5,80
3,1	10,12	8,12	6,92	6,11
3,2	10,70	8,57	7,29	6,44
3,3	11,31	9,04	7,68	6,77
3,4	11,92	9,52	8,07	7,11
3,5	12,56	10,01	8,48	7,45
3,6	13,21	10,51	8,89	7,81
3,7	13,88	11,03	9,32	8,17
3,8	14,56	11,56	9,75	8,55
3,9	15,27	12,10	10,20	8,93
4	15,98	12,65	10,65	9,32



4.2 Connection of VVVF controller

4.2.1 Power connections

4.2.1.1 Protective conductor

The protective conductor is to be **star-connected**.

Connect the protective conductor terminals of all components (braking resistor, inductor, motor, etc.) to the **star point** (main earth). This point should be as close to the VVVF controller as possible.

4.2.1.2 Connection to power supply

Select an appropriate **mains cable cross-section** (refer to VDE 0100 Part 523).

4.2.1.3 Fans

At devices bigger than FRC-F4 the power supply for the fan must be provided externally by the plant operator. The fan requires a supply voltage of 230V~/50Hz (60Hz). The fan power supply line must be fuse-protected (max. 6A).

The fan is connected to the terminals named L and N on the terminal block. Connection to PE is not mandatory, but should be done as the 2.5 mm² PE terminal if at all.

4.2.1.4 Motor phases

Select an appropriate **mains cross-section** (refer to VDE 0100 Part 523).

Connect the **motor phases U, V, W** using a **shielded cable**. Make sure the shield is connected to PE firmly (use a metal clamp) and as close as possible to the VVVF controller .

4.2.1.5 Braking resistor

Connect the **braking resistor** (terminals + and **RB**) using a **shielded cable**. Make sure the shield is connected to PE firmly (use a metal clamp) and as close as possible to the VVVF controller.

4.2.2 Low-voltage connections

4.2.2.1 Encoder

4.2.2.1.1 Square wave encoder

Connect the **incremental encoder** using a **shielded cable**. Make sure the shield is connected to PE firmly and as close as possible to the VVVF controller (use a metal clamp).

Make sure that the incremental encoder is connected to the VVVF controller correctly. The terminal assignment is as follows:

Terminal	Function	Remark
30	+5V	Supply voltage for TTL encoder
31	+ 15V	Supply voltage for HTL encoder
65, 66	GND	Encoder ground connection
27	Signal track A	
28	Signal track B	
62	Signal track -A	Track A inverted
63	Signal track -B	Track B inverted
23	-15 V	Supply voltage (not required for standard encoder)

Note : The inverted encoder outputs (-A, -B) are not mandatory for operation.

4.2.2.1.2 Sine encoder

Connect the sine encoder to the 15-pole D-SUB socket at the front plate of the VVVF controller (to the right of the display). **The VVVF controller must be switched off before connecting the sine encoder !**

The pin assignment of the D-SUB socket is as follows:

D-Sub Pin	Function	Remark
1	+ 5V	Supply voltage for TTL encoder
2	GND	Encoder ground connection
3	Sin A+	Sine track A
4	Sin A-	Sine track A
5	Data+	Data (only with ECN1313)
6	Sin B+	Sine track B
7	Sin B-	Sine track B
8	Data-	Data (only with ECN1313)
9	Sense+	Voltage feedback
10	free	
11	Sense-	Voltage feedback
12	R+	Zero pulse
13	R-	Zero pulse
14	Clock	Transmission clock pulse (only with ECN1313)
15	Clock-	Transmission clock pulse (only with ECN1313)

Note : Since sine encoders use relatively low signal levels, make sure to provide neat, continuous shielding. If the encoder is bought from us, the connection cable is already ready-made. If you do not use a ready-made encoder cable, make sure to use shielded connectors and to connect the shield properly.

4.2.2.2 Drive command inputs

4.2.2.2.1 General

The drive command inputs are designed for an operating voltage of +24V. The +24V control voltage is provided by the unit itself, but it can also be provided externally.

The **input current at +24 V** is some **10 mA**.

4.2.2.2.2 Overview

Terminal	Function	Remark
15	V0	Creep speed
16	V1	Inspection speed
17	V2	Intermediate speed
18	V3	Intermediate speed
19	V4	High speed
20	+24 V	Drive commands supply voltage
50	VN	Fine levelling
51	RU	Travel direction DOWN
52	RO	Travel direction UP
53	GS	Controller enable
55	GND	Travel command ground terminal

Remarks:

Via terminal GS (terminal 53) the output stage is de-energized immediately

4.2.2.2.3 Setting the direction

The VVVF controller can be operated either with 1 or 2 direction signals. Configuration is done via the software (see Section querverweis).

1 direction signal:

The desired direction is set by using terminal RO (terminal 52):

RO	Response
0	none or stop
1	up-travel


2 direction signals:

The desired direction is set by using terminals RU (terminal 51) and RO (terminal 52):


RU	RO	Response
0	0	none or stop
0	1	up-travel
1	0	down-travel
1	1	none or stop

If a direction signal fails during the travel operation, the controller starts a deceleration ramp and stops. A change of direction signals during the travel operation results in a direct change of the required value sign up to a speed of 25 rpm. In the case of higher speeds, the change of direction command is ignored for safety reasons and a warning message is signalled on the display.

4.2.2.2.4 Control via floating contacts, internal control voltage



4.2.2.2.5 Control via floating contacts, external control voltage




Important Note!


The +24 V supply voltages of the control and the VVVF controller must never be connected at the same time.

4.2.2.2.6 Signal procedure at normal operation (example: up-travel at V4)

Explanations on start-up: The **time** at which the travel commands are received does **not play any role**. As soon as the VVVF controller receives the controller enable (**GS**), direction signal (**RO** or **RU**) and a speed command (**V4**), the relay ZS (main contactors) and after the time *ZB auf* the relay ZB (brake) are activated and initiate the start-up operation.




Explanations on stop procedure: As soon as the V4 command is withdrawn, the deceleration operation is initiated, as soon as the V0 command is withdrawn, the unit is decelerated to speed 0. After the unit has stopped, the relays ZS and ZB are switched off, the delay times can be parameterised.




4.2.2.2.7 Signal procedure at inspection

Note: When the inspection pushbutton is released, the **control** closes the **brake** and opens the **main contactors**. The set value runs to 0 within 200 msec. The relay timing (ZB, ZS) of the VVVF controller **does not play any role** in this case.



4.2.2.2.8 Signal procedure for levelling operation

Note : When the flush landing level is reached, the **control** closes the **brake** and opens the **main contactors**. The set value runs to 0 within 200 msec. The relay timing (ZB, ZS) of the VVVF controller **does not play any role** in this case.



Make sure to wait for at least 1 sec. between two levelling operations so that the ropes and the mechanical equipment can settle. Otherwise it may happen that the elevator keeps levelling all the time without coming to a rest.

4.2.2.3 Digital inputs

Terminal	Function	Remark
21	Analog IN1	Analogue input 0 to 10 V, free
22	Uniln1	Digital-analogue input + 24 V for emergency operation
24	Digital IN1	Digital input + 24V (programmable)
25	Digital IN2	Digital input + 24V (programmable)
60, 61	GND_EXT	Ground inputs/outputs

4.2.2.4 Motor PTC input

Terminal	Function	Remark
35	TMS+	Motor PTC
36	TMS-	Motor PTC

4.2.2.5 Relay outputs

Terminal	Function	Remark
3	normally open contact	Relay TÛ (fault messages)
4	make contact	Relay TÛ (fault messages)
5	normally closed contact	Relay TÛ (fault messages)
6	normally closed contact	Relay ZS (travel contactor control)
7	make contact	Relay ZS (travel contactor control)
8	normally open contact	Relay ZS (travel contactor control)
9	normally closed contact	Relay ZB (brake control)
10	make contact	Relay ZB (brake control)
11	normally open contact	Relay ZB (brake control)
12	normally closed contact	Relay EÛ (signal for prematurely open doors)
13	make contact	Relay EÛ (signal for prematurely open doors)
14	normally open contact	Relay EÛ (signal for prematurely open doors)

4.2.2.6 Incremental encoder signals for shaft copying of the elevator control

Some elevator control systems use the output signals of the incremental encoder for shaft copying. The VVVF controller makes the processed encoder signals available at terminals 28 and 64. Note : The outputs are open collector stages (without downstream driver stage). The maximum output current is **2 mA**.

Terminal	Function	Remark
29	Encoder A	TTL-level, fmax=200 kHz, I _{max} = 2 mA
64	Encoder B	HTL-level, fmax=70 kHz, I _{max} = 2 mA
65, 66	GND	Encoder ground connection

4.2.2.7 Digital outputs

Terminal	Function	Remark
58	Digital Out 1	"Brake monitoring" output
59	Digital Out 2	"Controller ready" output
56	Digital Out 3	"Load direction" output
60, 61	GND_EXT	Ground inputs/outputs


Remarks:

When the unit is switched on it will take several seconds until it is ready for service due to internal self-tests. During this time no travel commands from the control will be accepted. At **terminal 59** (controller ready) a "+24"-signal appears as soon as the unit is ready for service.

4.2.2.8 RS-485 interface / DCP mode

Terminal	Function	Remark
32	RS485-Z	semi-duplex interface
33	RS485-Y	
67	RS485-A	semi-duplex interface
68	RS485-B	

To realize the DCP connection, terminal 67 and terminal 68 must be connected to the control system.




5 Commissioning

5.1 Use of the VVVF controller

5.1.1 Control elements

The user interface of the VVVF controller comprises a 2-line LC-Display, a keyboard with 4 keys and a 9-pole SUB-D plug for connection of an external programming device (PC with PowerControl for Windows) or a modem.



Currently, the following languages are supported:

- German
- English
- Turkish
- Spanish
- French
- Polish

Every function of the controller is to be selected and set by the 4 keys. The following functions are allocated to the keys:



Key "E": Selection of the menu item displayed and scrolling down in sub-menus, acknowledgement of data entered and filing of modified parameters ("Enter").

Key "C": Leaving submenus, rejecting modifications ("**Cancel**").

Arrow key "↶": Moving on a menu level, increasing values

Arrow key "↷": Moving on a menu level, reducing values

5.1.2 Entering parameter values



Entering values in order to change parameters is very easy by using the keyboard.

Press "E" to activate "Edit mode". Now the first line of the display shows the current value of the selected parameter. In the second line you can edit this value.

Use the "↑←" key to increase the value. Use the "→↓" key to reduce it. The increment increases dynamically if the key is pressed continuously. In this way it is also very easy to change parameters over a very large range.


The adjustment range is limited by the minimum and maximum values of the corresponding parameters.

When the parameter has the required value, confirm it by pressing "E". Press "C" to cancel the action.

Note : For safety reasons, parameters cannot be changed during a travel operation !

5.1.3 Navigation in the menu

From the standard display, press the "E" key to enter the first menu level of the main menu (set-up).



Use the arrow keys to scroll through this menu level. The menu is designed as a circle, i.e. press "→↓" when you are on "Extended" to return to "Setting".

This ring-like structure is found in all sub-menus, too.

Press the "E" key to open the first menu item of the selected main menu. Here, use the arrow keys to scroll through the individual menu items and press the "E" key to open the selected sub-menu.

Use the "C" key anywhere in the menu to return to the previous hierarchy level. "C" will always open the first item of the higher-order menu where you have branched into the sub-menu by using the "E" key.

If you press the "C" key in the first menu level (main menu), you will return to the standard display.

5.2 Factory settings, parameter overview


The parameters have been preset in our factory, so on installation of the elevator you can simply set the elevator parameters and then operate the elevator in a controlled manner. For easy setting the display offers a special- menu **short setting**, in which the parameters are called up automatically.

Parameter	Display text	Setting range	Basic setting	Remark
Speed				
Creep speed	V0	1 - 630	100 rpm	mm/sec
Inspection	V1	1 - 1500	300 rpm	optionally in mm/sec
1st intermediate speed	V2	1 - 3000	1000 rpm	optionally in mm/sec
2nd intermediate speed	V3	1 - 3000	1380 rpm	optionally in mm/sec
High speed	V4	50 - 3000	1380 rpm	optionally in mm/sec
Fine leveling	VN	1 - 270	75 rpm	optionally in mm/sec
Evacuation speed	VE	1 - 630	100 rpm	optionally in mm/sec
Levelling monitoring	EÜ	0 - 1800	300 rpm	optionally in mm/sec
Deceleration monitoring	BÜ	0 - 1800	300 rpm	optionally in mm/sec
Starting behaviour				
time of starting jerk	AR	100 - 3000	1500 msec	
type of starting jerk (static, dynamic)	AR_TYP	0 - 1	1	Standard: dynamic
speed of starting jerk	VA	1 - 180	10 rpm	optionally in mm/sec
Times/Distances				
acceleration	HL_V4	1000 - 10000	2500 msec	in mm
deceleration ramp	B_V4	1000 - 10000	2500 msec	in mm
electrical stop	EH	300 - 3000	1000 msec	in mm
travel curve start time	SF	100 - 30000	300 msec	
delay time relay contactors	ZS	100 - 1000	300 msec	
delay time relay brake close	ZB_close	0 - 1000	200 msec	
delay time brake open	ZB_open	0 - 3000	100 msec	
Regulator				
gain speed regulator	n_P	2 - 200	30	
gain speed regulator	n_I	40 - 9999	1000 msec	
gain starting regulator	K_START	50 - 500	150 %	
gain starting regulator	K_STOP	50 - 500	150 %	
stillstand regulator	Halte_P	0 - 10000	30	
stillstand regulator	Halte_I	1 - 9999	1000	
limit starting regulator	GA	0 - 3000	90 rpm	
torque anticipation	MV	0 - 500	100	
load compensation	LV	100 - 900	500	
General settings				
nominal motor current	I_MOT	2 - 200	FRC-rated current	motor type plate
nominal motor voltage	U_MOT	150 - 700	400 V	motor type plate
nominal motor speed	n_MOT	50 - 3000	1350 rpm	motor type plate
nominal motor frequency	f_MOT	20 - 100	50 Hz	motor type plate
cos (phi)	cos(phi)	30 - 99	80	motor type plate
number of encoder pulses	Encoder	500 - 4096	1024	Square wave encoder
voltage supply for encoder	Ub-Encod.	5 - 15	5 V	Square wave encoder
Mains voltage	U_MAIN	220 - 440	400 V	Mains voltage
Extended menus				
Synchronous machine				
nominal motor current	I_MOT	2 - 200	FRC-rated current	motor type plate
nominal motor voltage	U_MOT	150 - 700	400 V	motor type plate
number of motor pole pairs	Pole pairs	1-100	2	motor type plate
number of encoder pulses	Encoder	500 - 4096	1024	Sine encoder
load angle offset	RhoOffset	-32768 - 32767	0	automatic measurement
encoder evaluation method	Sine mode		0	
load angle correction	Rho_corr	0 - 1	0	currently without function
Open-Loop 1				
rotor time constant	TADJ_TRM	0-1000	80	
slip correction	Slipcorr	0-32767	10000	
torque anticipation	MV	0-500	100	
load compensation	LV	100-900	500	
start-up voltage	U_Start	0-32000	4000	automatic determination
motor resistance	R1_Motor	700		automatic determination

Open-Loop 2 rotor time constant torque anticipation load compensation magnetization torque Voltage offset Motor resistance	TADJ_TRM MV LV Umotor_lmy Umotor_lq UOffset R1_Motor	0-1000 0-500 100-900 0-100 0-100 0-500 700	80 100 500 7 0 0	automatic determination automatic determination automatic determination
Extended general settings transmission Pulley diameter suspension	trnsmiss pull. diam susp dev	0-5000 0-1000 0-5	0 0 mm 0	actual transmission*100
Extended travel curve floor to floor Roundings floor to floor Mode travel curve Transitional time at speed changes Acceleration time to speed V3 Acceleration time to speed V2 Deceleration time from speed V3 Deceleration time from speed V2 Reference distance	SC R_SC FK-Mode T V4->Vz HL_V3 HL_V2 B_V3 B_V2 S-Ref	0 - 1000 0 - 1000 1 - 3 0 - 5000 0 - 5000 0 - 5000 0 - 5000 0 - 500	500 300 2 0 0 0 0 0 0 mm	S-curve Transitions V4 <-> V3 or V2 in mm optionally in mm optionally in mm optionally in mm Position correction at direct landing
Extended regulator settings inertia positioning controller scan time torque limit Max. motor current P-amplification current regulator I-amplification current regulator D-amplification speed regulator torque smoothing	T LR TA IQ_MAX IMAX_MOT Strom_P Strom_I n_D Iqsoll_T1	0 - 10 0 - 300 1000 - 10000 1 - 100 100 - 300 1-300 1-32767 0 - 100 0 - 5	0 100 % 5000 usec 100 % 200 % 15 4000 0 0	for V-belt drive Position controller amplification
Error configuration enable error motor adaptation enable error phase failure enable error overload Auto error reset	motor ad. phase fail. overload Auto reset	0 - 1 0 - 1 0 - 1 0 - 2	1 1 1 1	error enabled error enabled error enabled autom. error reset
Inputs/outputs Encoder input encoder input Function digital input 1 Function digital input 2 encoding of drive commands Configuration of direction signals Monitoring runtime monitoring contactor monitoring	T-1 direction Digin1 Digin2 drive commands only RO(1) runtime cont.mon.	0-4 0-1 0-1 0-1 0-1 0-1 0-600 0-1	0 0 0 0 0 0 0 sec 0	smoothing of actual speed value normal / inverted error reset/contactor monitoring error reset/contactor monitoring parallel/binary RO or R0+RU for contactor design only contactor drop-out monitoring
DCP command source s-shape of deceleration curve	S-curve	Terminals / DCP 1 - 25	Terminals 10	only effective in the case of DCP2
VVVF controller enable sine controller switching frequency of IGBT's enable current regulator adaptation overload factor of VVVF- controller Break-away torque for catching test	SinBoard f_PWM Adaption Max.current V1Maxjerk	0 - 1 6 - 15 0 - 1 100 - 200 0 - 1	0 14 kHz 0 200 % 0	only with additional evaluation unit automatic measurement only at V1

5.3 Menu overview

The menu has an hierarchical structure and assembles functions belonging to one another in easily understandable submenus. To facilitate work with the display-menu, the items are nearly the same as in the PC- Windows program. You will find a **complete summary of all sub-menus** on the following page.



5.4 Switching on the power supply

```
Setup - wait
*****
```

After switching on, the unit is running a self-test, which is demonstrated on the display by this message.

```
Ready
0rpm      0A
```

As soon as the unit is ready for operation, the standard display screen appears:

The standard display modus shows the actual operation mode of the unit in the first line, in the second line actual motor speed and actual motor current are displayed.

5.5 Adaptation of the controller parameters to the system

Press the Enter key ("**E**") twice to open the Fast Setting menu.

Use this menu to set all parameters which are necessary for an initial run. The converter leads you automatically to the relevant parameters where values have to be entered. These are:

```
Setting
Fast setting
```

- nominal motor current
- nominal motor voltage
- nominal motor speed
- nominal motor frequency
- cos(phi).
- number of encoder pulses
- encoder supply voltage
- mains voltage
- High speed V4.

```
Fast setting
I_Mot      24 A
```

```
Fast setting
U_Mot      400 V
```

---> The converter switches automatically to the next parameter as soon as a value has been entered.

```
Fast setting
quit with <E>
```

The unit quits quick set-up as soon as the last menu parameter has been entered.

Quick set-up can also be aborted at any time using the "**C**" cancel key. It is also possible to jump between parameters within this menu using the cursor key and continue setting adjustments at any point.

General tips for the adaptation of the VVVF controller to the motor:

Some drive manufacturers (e.g. Schindler) always "stamp" their drives with the **synchronous speed** (no slip). This must not be mixed up with the **nominal speed** the drive achieves when loaded. The slip, i.e. the difference between the synchronous speed and the nominal speed is **approx. 2.5 to 4 %** in the case of **one-speed motors for VVVF controllers**. In the case of 50 Hz motors with 2 pole pairs, this corresponds to a nominal speed of approx. **1440 – 1465 rpm**. In the case of **pole-changing motors**, the slip is approx. **5 to 8 %**, which corresponds to a nominal speed of **1380 to 1425 rpm**.

To ensure a perfect travel behaviour, the nominal speed must be adjusted at the VVVF controller. This is always less than 1500 rpm in the case of 50 Hz motors !



5.6 First travel operation

Issue travel command from the control system. The following commands are required for a travel operation at speed V1:

Travel up: GS, RO and V1
 Travel down: GS, RU and V1

Ready		
0rpm		0A

In the case of an upward movement of the cabin, a positive speed must be displayed.

Running up V1		
300 rpm		17 A

Running down V1		
-300 rpm		17 A

In the case of a downward movement, the value is negative.

Tip for checking the incremental encoder:



After entering system-related data, we recommend checking the general function of the incremental encoder before running for the first time. This can be done easily:

Ready		
0rpm		0A

Call up the standard display on the unit's display. If you are in a sub-menu, press the "C" key as often as necessary until the following text is displayed.

Ready		
231rpm		0A

Release brake briefly so that the cabin drifts upwards a few centimetres and observe the display at the same time. A **positive speed** must be displayed. If the speed is negative, the sensor tracks on the unit have to be reversed (terminal 27, 28 and 62, 63). If no speed is displayed, check the encoder connection and the entered data (number of encoder pulses and supply voltage) in the menu *General Settings*.

If the assignment between the sense of rotation of the motor (terminals U, V, W) and incremental encoder tracks is defective or if defective or no incremental pulses are detected, the motor runs for some 2 seconds before it is switched off and the error message "Wrong tacho polarity" and "no start-up" is displayed (see troubleshooting **Section 8.1**).

5.7 The Menu

5.7.1 Selection of units

The setting of the speeds and the distances/times can be done either in reference to the motor speed (rpm) or in reference to the cabin speed (m/sec).


The following parameter-groups can be set in the 2 unit modes:

Refer to:	Motor	or	cabin
Speeds:	rpm	or	m/sec
Ramps:	msec	or	mm

If you want to set the units in meter/second you must enter the correct values for transmission, pulley-diameter and suspension correctly. **If one of these parameters is not entered, the unit mode can't be changed from rpm to m/sec.**

As a standard, the unit mode is set to rpm. The following illustrations all show rpm unit mode.

The steps for changing the unit mode to m/sec. are explained in detail in **Section 5.7.6.3.**



5.7.2 Error messages

Operational errors are displayed by a flashing error message.



In the second line of the display is shown the cause of the error in plain text

Sometimes, the controller recognises several errors at a time. In this case, a list of these errors is displayed. You can scroll through this list using the arrow keys.

5.7.3 Acknowledging faults

The unit returns to its normal operating mode after a fault has been acknowledged and the standard message is shown on the display - as long as the fault has been rectified. The following possibilities are available for acknowledging faults:

5.7.3.1 Manual acknowledgement using the unit's keyboard

Press the Enter key ("E") on the converter. If the cause of the error is still present (e.g. "overtemperature"), the error message can be deleted from the display, but the TŪ relay remains open (safety circuit open). The error is still active in the background. The error message can be activated again in the menu "Display" - "Errors".


5.7.3.2 External acknowledgement by a +24V signal

Application of a +24V signal to the appropriate digital input. The converter only reacts to the positive voltage edge ("permanent acknowledgement" not possible) for safety reasons.


5.7.3.3 Acknowledgement by the unit itself by auto-fault reset

Activate/deactivate in the **Fault Configuration** menu (see **Section 5.7.8.6**).


5.7.4 Setting – programming the converter



5.7.4.1 Setting speeds




By this item set the different operating speeds. As a standard, the speed is set in rpm (revolutions per minute). The setting refers to the speed of the motor shaft. Alternatively, you can set the speeds in mm/second (**Section 5.7.6.3**).




Speeds

By key „E“ branch to the different speeds. By key „C“ return to the main menu.

The following operating speeds can be set.



V0: creeping speed.



V1: inspection operation speed.

Speeds	
V2	1000rpm

V2: 1. intermediate speed.

Speeds	
V3	1000rpm

V3: 2. intermediate speed.

Speeds	
V4	1380rpm

V4: high speed.

Speeds	
VN	75rpm

VN: leveling speed.

Geschw.	
VE	100rpm

VE: evacuation speed (the emergency mode is explained in **Section 5.10**).

Speeds	
EÜ	300rpm

EÜ: Assisting the function „doors starting to open during slowing down“. As soon as during slowing down the speed falls below the set value, the related relay „EÜ“ is energised. The elevator control unit is able to recognise this signal and initiates door opening. If the set speed is, however, exceeded, the relay is de-energised again.

Speeds	
BÜ	300rpm

BÜ: Brake monitoring. . If the motor speed falls below this value, the output **Digital Out1** (terminal 58) is activated, if the set speed is exceeded, the output is reset again. By means of this function it is possible to monitor the braking function.

In case of **doors starting to open during slowing down**, for the EÜ-releasing point choose a value that allows an operation in compliance with EN 81 resp. TRA.

For the releveling function set **VN** to approx. 3% - 5% of the rated motor speed.



Note: Between repeated releveling operations by all means a pause of **at least 1 sec** each is to be kept, in order that mechanical components and particularly the ropes can settle.

The speeds are set in rpm. A conversion from rpm to cabin speed (m/sec) is possible with the following formula.

$$VKN[m/sec] = \frac{n[1/min] * \pi * DD[m]}{KZU * IW * 60}$$


$$n[1/min] = \frac{VKN[m/sec] * KZU * IW * 60}{\pi * DD[m]}$$

- n:** motor speed in revolutions per minute (rpm)
- VKN:** cabin speed in m/sec
- KZU:** suspension
- IW:** transmission ratio
- DD:** driving pulley diameter in m

5.7.4.2 Setting the starting behaviour

Setting
Starting jerk

By the items of this menu the behaviour of the elevator during starting is defined.



By pressing key „E“, you can branch in the items of the menu to set the parameters. By key „C“ you return to the main menu.

ehaviour of the elevator during starting is defined by the following parameters:

Starting jerk
AR 1000ms

Duration of the whole starting operation

Anfahrdruck
VA 10rpm

Starting motor speed

Starting jerk
AR_TYP 1

You can choose between a static or a dynamic curve:
static (0): after the time AR the acceleration begins.
dynamic (1): if the actual speed has reached a minimum threshold ($VA/2$), the acceleration ramp starts.


Appropriate setting of the starting parameters will result in a „smooth“ starting. The elevator car will smoothly and without jerk be freed from the frictional grip.

5.7.4.3 Setting the times/distances

Setting
Times

The form of the drive curve is stipulated using these parameters.

By pressing key „E“, you can branch in the items of the menu to set the parameters. By key „C“ you return to the main menu



You can set the ramps in milliseconds or in millimetre (**See section 5.7.6.3**)

The following parameters are available:

Times	
HL_V4	2500ms

Acceleration to speed V4

Times	
B_V4	2500ms

Deceleration from V4 to standstill in the case of direct landing. In the case of travel to V0, the set value is reduced proportionally to the ratio V4/V0.

Times	
EH	1000ms

Duration of the braking ramp "electrical stop". This ramp is initiated as soon as the drive command V0 is ceased. Time „EH“ defines the time to elapse after cease of V0 up to standstill.

Times	
SF	300ms

Time lag between starting the travel curve and receiving a drive command.

Times	
ZS	300ms

Time from applying the brakes to the relay ZS (main contactor) shutting off upon stopping.

Times	
ZB zu	200ms


Time from stop (set value 0) until application of the brake (relay ZB shut-off).

Times	
ZB auf	100ms

Time from start command until opening of the brake (relay ZB activated).

Timing diagrams concerning the sequence of signals are given in **Chapter 4.2.2.2** .

5.7.4.4 Setting the speed controller



The items of this menu define the behaviour of the speed controllers.

By pressing key „E“, you can branch in the items of the menu to set the parameters. By key „C“ you return to the main menu

Explanation of terms P (Proportional) and I (Integral) - amplification of controller:

- With the **P**-factor it is possible to define an **immediate response** to speed deviations, i.e. it is responsible for the immediate response of the controller. High values result in rough running (vibrations).
- The **I**-component is responsible for the accuracy of the controller. Through the I-component, the controller generates a continuously increasing torque until there is a deviation between the set value and the actual value (system deviation). The I-portion determines how fast the torque increases - the smaller the I-portion (integration time) the faster the torque increases. Values which are too low may result in instability of the control system (vibrations).

The factory settings are relatively "soft" so that the controller will work in the stable range in any case. Generally, the basic factory settings are sufficient to ensure a satisfactory travel and control behaviour. The controller settings must be optimised in special cases only.



Regulator structure of the VVVF-controller:

In order to enable optimum control of the whole travel range, several regulators are used:


Stopping regulator (Halte P, Halte I): Only used for stopping the drive when the brake is opened

Speed regulator (n P, n I): Activated during the travel operation. The amplification can be changed as from a definable speed threshold (GA). The amplification values for acceleration and deceleration can be set separately (K START, K STOP).


Position regulator (LR): During the deceleration operation, a position regulator is active.




Proportional coefficient of the speed controller.



Integration time of the speed controller.



Proportional coefficient of the stillstand controller.



Integration time of the stillstand controller.

Control settings
GA 49 rpm

Switch-over threshold for speed regulator amplification

Control settings
K START 150%

Increase of starting regulator's gain in refer to the speed regulator

Control settings
K STOP 150%

Increase of stopping regulator's gain in refer to the speed regulator

Control settings
MV 100

Torque pre-control during acceleration and deceleration. Overshooting and undershooting after the ramps can be eliminated with this parameter.

FU operating mode 4
LV 500%

Preset load for load equilibrium: A basic torque is preset when the brake is opened (static load compensation). This parameter is to be set in percent.

LV = 500 means symmetrical weight equilibration, no preset torque.

Values < 500 mean a preset torque in down direction.

Values > 500 mean a preset torque in up direction.

A difference of 100 equals a preset torque of 10 %.

Example :

LV = 400 -> a preset torque of 10% in down direction

LV = 700 -> a preset torque of 20% in up direction

5.7.4.5 Adapting the unit to the system

In order for the vector control to work at the optimum operating point, the system data must be entered:

General settings
I_MOT 32A

rated motor current

General settings
U_MOT 400V

rated motor voltage

General settings
n_MOT 1350rpm

rated motor speed

General settings
f_MOT 50Hz

rated frequency of the motor voltage

General settings
cos(phi) 80

power factor of the motor. The value given on the type plate of the motor must be multiplied by 100.

General settings
Encoder 1024

number of encoder pulses

Anlagedaten
Ub Encod. 5V

incremental encoder supply voltage. Please make sure that the encoder is connected to the corresponding terminal of the converter (terminal 30 = +5V, terminal 31 = +15V).

Anlagedaten
U Main 400V

Mains voltage

5.7.5 Display/Scanning operating variables

In this menu the operating variables of the converter are displayed.

FRC
Display

Display
Act./Set Values

Display
Inputs/Outputs

Display
Errorstack

Anzeigen
Statistics

Display
Actual Faults

5.7.5.1 Display of actual and set values

5.7.5.1.1 Speed

Act./Set Values
n-act 1252rpm

Current motor speed

Act./Set Values
n-nom 1250rpm

Current speed set value

5.7.5.1.2 Motor current and torque

Act./Set Values
M-act 23%

converter torque output related to its maximum torque. Note : In the case of drives under load (e.g. "empty down"), the maximum displayed torque should not be more than 80 % in order to ensure there is sufficient reserve for control.

Act./Set Values
I-act 18A

Motor current (effective) in Amperes.

5.7.5.1.3 Other variables

Act./Set Values
U_zwk 563V

DC link voltage of converter

Act./Set Values
F_s 43Hz

Stator frequency of motor

Act./Set Values
U_s 386V

Stator voltage of motor in Volts. Voltage losses due to dead times and transition resistances are not considered, thus the actual motor voltage is slightly lower.

Act./Set Values
U_s 96 %

Stator voltage of motor in %, related the maximum value.

```
Act./Set Values
Temperat.    42 °C
```

Cooling body temperature

```
Act./Set Values
Iq/Iqsoll    102%
```

Information on the converter/motor adaptation. This parameter is only used for service purposes.

5.7.5.1.4 Maximum value storage

```
Act./Set Values
U_zwk_max    678V
```

Maximum value storage for DC link voltage. Is deleted when the unit is switched off.

```
Act./Set Values
I_max        56A
```

Maximum value storage for current. Is deleted when the unit is switched off.

```
Act./Set Values
T_max        72°C
```

Maximum value storage for temperature. Is deleted when the unit is switched off.

5.7.5.1.5 Bar graph display of deviation between required and actual speeds

```
Act./Set Values
Cont.Difference
```

The response to setpoint changes by the regulator, i.e. its precision shown on a bar diagram, can be evaluated in this menu. One line is displayed when at rest. Each additional line means a further difference between actual and required speed of 5 rpm.

```
Cont.Difference
-
```

At rest, no control difference

```
Cont.Difference
----
```

Drive (example), speed deviation actual-required = 15 rpm

5.7.5.2 Display of inputs/outputs

5.7.5.2.1 Drive commands

```
Inputs/Outputs
Drive commands
```

The read drive commands are displayed as plain text.

```
Drive commands
GS RO V4 V0
```

5.7.5.2.2 Digital inputs

```
Inputs/Outputs
Digital Inputs
```

The read digital inputs are displayed as plain text.

```
Digital Inputs
Din1 Din2
```

5.7.5.2.3 Digital outputs

```
Inputs/Outputs
Digital Outputs
```

The read digital outputs are displayed as plain text.

```
Digital Outputs
Dout1
```

5.7.5.2.4 Relay outputs

```
Inputs/Outputs
Relay Outputs
```

The activated relay outputs are displayed as plain text.

```
Relay Outputs
ZS ZB
```

5.7.5.3 Display of errorstack

```
Display
Errorstack
```

The unit is equipped with an internal memory filing the 10 latest errors. By this menu item, the memory can be read. When this menu item is called in, at first the latest error (highest error No.) is displayed. By key "↓→" you can scroll down to error No. 1. ..

```
Error 10: 65432
B:0000 C:0008
```

Each error is displayed with its number, the number of travels at which the error occurred and a code number of the error.

```
*** Error ***
Undervoltage ZWK
```

To read the cause of the error in plain text, press „E“. Basing on the error code, a list of plain texts is determined, which you can scroll through by means of the arrow keys. By „C“ you can return to the display of the error. Example left: Fault number 5, "undervoltage", occurring at 65432 elevator drives.

```
Errorstack
...erase ? <E>
```

While leaving the menu, you have the possibility to erase the memory by pressing the “E” key. This, however, is only possible with the output stage switched off, i.e. not during a travel operation. With the “C” key you can leave the menu without erasing the memory.

```
Errorstack
..erasing
```

5.7.5.4 Display of statistical data

```
Display
Statistics
```

From this data, the degree of utilization of the converter can be learned.

```
Statistics
Op. Time 1400h
```

Operating time in which the unit was connected to mains supply.

```
Statistics
Act. time 239h
```

Time in which the output stage was active, i.e. travel operations were carried out.

```
Statistics
Starts 67890
```

Number of travel operations carried out. Switching on and off the output stage is interpreted as a travel operation.

```
Statistics
Runat1.8 32
```

Number of travel operations carried out in which the rated unit current was exceeded by a factor of 1.8.

```
Statistics
Time_Tmax 0min
```

Time in which the unit was operated at maximum temperature.

5.7.5.5 Display of current errors

```
Display
Actual Faults
```

This menu can be used for checking any errors which may be present but are not flashing on the display. This is the case if the error display was shifted to the background using the "E"-key.

```
*** Fault ***
Undervoltage ZWK
```

5.7.6 System settings

Here you set parameters referring to the unit but not to the elevator plant or its operation.

```
FRC
System
```

```
System
Code no.
```

```
System
Language
```

```
System
Units
```

```
System
Op. Mode
```

5.7.6.1 Unit password protection

```
System
Code no.
```

You can protect your settings (parameters) against unauthorised modification by a code of 4 digits at a maximum. If a code defined, you will be requested to enter this code when you try to change a parameter. You will have to enter this code correctly, otherwise you cannot change parameters.

```
Code no.
enter
```

By the following menu items, you can organise your code:

```
Code no.      0
              0
```

Entering a code previously defined. The unit will ask you to enter the code. Activate the editing mode by pressing the "E" key and enter the code.

```
Code no.
ok...
```

If the code entered complies with the code saved in the unit, a corresponding message will be displayed.

```
Code no.
Error
```

Otherwise an error will be signalled.

```
Code no.
change
```

Press "C" to quit editing mode.

Entering a new code or editing a previously defined code. The unit will ask you to enter a code.

```
Code no.      0
              0
```

Activate the editing mode by pressing the "E" key and enter the code.

```
Code no.
repeat
```

The unit will ask you to enter the code again. Activate the editing mode by pressing the "E" key and enter the code again.

Code no.
ok. . .

If both codes entered match, a corresponding message will be displayed and the code will be activated.

Code no.
Error

Otherwise, an error message will be displayed and the code entered will be rejected.

Enter code "0" to switch off the code check. You can use any code value other than "0".

When the unit leaves the factory, it is not code-protected.

5.7.6.2 Setting the language

System
Language

Here, you can set the language to be used for all texts and messages on the display.

Language
German

The selected language is activated by pressing the "E" key.

Currently, the following languages are supported:

- German
- English
- Turkish
- Spanish
- French
- Polish

5.7.6.3 Units - rpm or m/sec

The setting of the speeds and the distances/times can be done either in reference to the motor speed (rpm) or in reference to the cabin speed (m/sec).

The following parameter-groups can be set in the 2 unitmodes:

Speeds: **motor speed [rpm]** or **cabin speed [m/sec]**

Ramps: **Time [msec]** or **distance [mm]**

System
Units

If you want to set the units in meter/second you must enter the correct values for transmission, pulley-diameter and suspension correctly (**see Section 5.7.8.3**). **If one of these parameters is not entered, the unit mode can't be changed from rpm to m/sec.**

Units
m per sec

Einheiten
rpm

As a standard, the unit mode is set to rpm.

5.7.6.4 Unit operating modes

System
Operating Mode

The following operating modes can be used:

Operating Mode
Vektor Asynchron

Field-oriented mode with asynchronous machine

Operating Mode
Open Loop 1

F/U control with asynchronous machine (see **Section 5.9.1**)

Operating Mode
Vektor Synchron

Field-oriented mode with synchronous machine, gearless (see **Section 5.8**).

Operating Mode
Open Loop 2

F/U control with asynchronous machine (see **Section 5.9.2**)

5.7.7 Information menu

Here, you can find information on the unit, which is useful in particular when it comes to telephone service.

FRC
Info

Info
Hardware

Info
Software

Info
Operating Mode

5.7.7.1 Hardware

Info
Hardware

Select the menu by using the "E" key. Once opened, you can scroll through the individual submenus using the arrow keys

Size
FRC3 - 16A

Size of converter and rated current

Power unit
Q1-Q7

Power unit version

Encoder unit

Information on additional unit for special encoders (sine encoder, ..), if applicable. Incremental encoders do not require an additional unit.

5.7.7.2 Software

Info
Software

Select the menu by using the "E" key. Once opened, you can scroll through the individual submenus using the arrow keys

```
Software
Basis 18.050.01
```

Software version basic controller.

```
Software
Sinusc.          0
```

Software version sind-controller.

5.7.7.3 Operating mode

```
Info
Operating Mode
```

```
Operating Mode
Vektor Asynchron
```

The acitvated Operating Mode is displayed (s. **Abschnitt Fehler!** Verweisquelle konnte nicht gefunden werden.).

5.7.8 Extended menus

Here, you will find functions which are not (or rarely) needed for the standard operation of the converter.

```
FRC
Extended
```

```
Extended
Synch. Machine
```

```
Extended
Open Loop
```

```
Extended
Ext.gen.settings
```

```
Extended
Ext.drive curve
```

```
Extended
Extended Control
```

```
Extended
Error Config.
```

```
Extended
Works setting
```

```
Extended
Inputs/Outputs
```

Extended Monitorings

Extended DCP

Extended Failures

Extended Converter

Extended Trace/Debug

5.7.8.1 Synchronous machine

Extended Synch. machine

This menu contains the parameters for an operation with synchronous machines (see **Section 5.8**).

5.7.8.2 Open-Loop Mode

Extended Open Loop

This menu contains the parameters for an operation without incremental encoder (see **Section 5.9**).

5.7.8.3 Extended general settings

Extended Ext. gen. settings

In order to change the units from rpm to m/sec information on the pulley diameter, transmission and suspension of the cabin are required.

Ext. gen. settings Gear.trans. 0

Here, you must enter the **transmission * 100**.

Example : Transmission = 53:2 --> entered value 26,5 * 100 = 2650

Ext. gen. settings D-drive 0mm

Here, you must enter the pulley diameter in mm.

Ext. gen. settings Susp. 0

Here, you must enter the suspension of the cabin.


Example : 1:1 --> entered value 1, 2:1 --> entered value 2

5.7.8.4 Extended drive curve settings

Extended Ext. drive curve

5.7.8.4.1 Floor to floor correction

The VVVF controller operation comprises an automatic floor to floor correction, providing distances covered at low speed, regardless of the overall length of the travel (between two adjacent landings or over a long distance).



If the drive command (3) is cancelled during the acceleration ramp, a floor-to-floor travel operation is initiated. The shape of this floor-to-floor travel operation, however, can only be influenced significantly using the parameters SC and R-SC if the drive command is cancelled early, so that there is a sufficient distance available for the required shape of the curve. If the travel command is cancelled a short time before the final speed is reached, the shape of the curve cannot be varied.

Ext. drive curve	
SC	500

(1) High values for SC result in high speeds and correspondingly short travel times.

(2) Low values for SC result in low speeds and correspondingly long travel times.

Ext. drive curve	
R_SC	300ms

With R_SC the rounding of the curve can be set. R=0: no rounding
R=1000: max. rounding



Note : The floor-to-floor travel operation is intended for high speed V4 only !

The distance of the floor-to-floor travel calculation to be covered is determined from V4 and B_V4.

5.7.8.4.2 Set value - ramp shape

Here, you can change the basic S-shape of the acceleration and deceleration ramps.

Ext. drive curve	
FK-Mode	2

1: higher peak acceleration at the turning point

2: comfortable setting (standard)

3: linear ramp without S-shape

5.7.8.4.3 Speed transitions

As a standard, high speed V4 is used as the basis for the set value ramps. That means, HL and B relate to this speed. If acceleration is to be done to another speed, e.g. V2, the calculation of the acceleration time is done such that the acceleration is the same as in the case of acceleration to V4. As a result the ramp times are shorter by the factor of the selected speed divided by V4. In the case of speed transitions with a small difference this means that small ramp times with small roundings are generated, which can result in an uncomfortable driving behaviour.

Using the following parameters, this calculation based on the constant acceleration can be avoided, and **the required sections of the travel curve can be set individually.**

Activation is done by entering values **greater than 500 msec**, smaller values are automatically set to 0 and ignored by the travel curve calculator.

Ext. drive curve	
T V4->Vz	0ms

With this parameter, the transition time (independent of the speed difference) can be set from V4 to one of the intermediate speeds V3 or V2.

Ext. drive curve	
HL_V3	0ms

Here, you can adjust the ramp times and distances to the corresponding intermediate speed individually.

Ext. drive curve	
B_V3	0ms

Ext. drive curve	
HL_V2	0ms

Ext. drive curve	
B_V2	0ms

5.7.8.4.4 Direct landing with reference signal

Ext. drive curve	
S-Ref	100mm

If a reference signal is available which is to be evaluated, the distance of the reference signal from the leveling position must be entered here.

Activation of reference function:

Set parameter **S_REF** to a value > 0 to activate the function.

The required system data (transmission, pulley diameter and suspension) must be entered correctly (see Section). **If one of these data is not entered, i.e. if the corresponding parameter value is 0, the reference function cannot be activated!**

The reference function is only possible for speeds V3 and V4 !

Terminal functionality:

If the function is activated, **V0 terminal** is used for connection of the reference signal. **Speed V0 is not used in this case.** Note that some controllers (wrongly) use V0 for inspection travel operations. This is no longer possible if the reference function is activated. In this case, V1 must be used.

Reference signal of the elevator controller:

When the zone is reached, the reference signal must be switched to +24V and remain HIGH until the end of the travel operation.

5.7.8.5 Extended control settings

Extended Control
Extended Control

Extended Control
LR 100%

Extended Control
IMAX_MOT 200%

Extended Control
IQ_MAX 200%

Extended Control
Current_P 15

Extended Control
Current_I 4000

Extended Control
T 0

Extended Control
Iqsoll_T1 0

Extended Control
TA 5000us

Extended Control
n_D 0

In the case of a deceleration to stop, i.e. during **stopping** or a **direct landing** operation, a **position controller** is active. This controller continuously compares the actual position to the set position and compensates any deviations. This is a prerequisite for an exact landing operation. By increasing the parameter LR, the position controller can be reinforced and position deviations can be balanced faster. If you enter 0, the position controller is switched off completely.

Note : An excessive gain can result in vibrations when the elevator stops.

Limitation of maximum motor current.

Maximum output torque of the controller. The torque output of the converter can be reduced (e.g. for TÜV inspections, for test purposes).

Proportional current regulator gain.

Note: Change parameters only after consultation with RST Elektronik.

I-gain current regulator.

Note: Change parameters only after consultation with RST Elektronik.

In the case of highly dynamic systems such as V-belt drives, a "software flywheel" can be activated here. This results in a smoother travelling behaviour. The appropriate setting must be determined in tests.

The variable of the speed controller can be smoothed in order to obtain a smoother behaviour.

Note: High values can result in vibration.

In case low-pulse encoders are used, the scanning time of the speed controller can be increased in order to obtain a better speed resolution. If the scanning time is too long, this can result in control vibrations.

After changing the scanning time, the unit must be switched off and on again in order for the new setting to become effective.

Note: Change parameters only after consultation with RST Elektronik.

Here, you can activate a differential (D) controller component. Normally, this is not required for the elevator application.

5.7.8.6 Configuring fault behaviour

Extended Error config.

It is possible to programme the reaction of the unit to certain fault conditions. This establishes whether an occurrence of a fault leads immediately to the system locking and a TÛ cumulative fault signal being triggered (TÛ-relay).

The parameters can be either 0 or 1.

- 1: Error is displayed.
Motor is stopped.
TÛ is released.
Drive commands are not accepted.
- 0: Error is displayed.
Elevator operation is continued.
TÛ not released by this error.
Drive commands are accepted.

The following fault messages can be masked off:

Error config. Phase mon	1
----------------------------	---

Depending on the hardware design, the devices are equipped with a phase monitor which monitors the mains voltage and responds if one or more phases fail.

Error config. Motorad.	1
---------------------------	---

"Motor adjustment": is triggered if the travel contactors are open or if the automatic current regulator optimisation function fails.

Error config. Mot.overl	1
----------------------------	---

"Motor overload" is released if the motor is overloaded. Significant discrepancy between power consumption and rated current. (Power consumption is much higher.)

Error config. Autoreset	1
----------------------------	---

Automatic acknowledgement of faults which have occurred is possible with the "**Auto fault reset**" parameter. The following configurations are possible:

- Parameter value 0:** The unit switches immediately to lock
- Parameter value 1:** In the event of a fault, the unit carries out an internal acknowledgement and is ready again after 3 seconds. This automatic acknowledgement is carried out a maximum of three times in direct series. The occurrence of a 4th fault causes the unit to switch to lock mode.
- Parameter value 2:** The number of fault acknowledgements is unlimited. In this case, locking should be taken over by control after a defined number of start attempts.

Note : The control must switch off all drive commands if a controller fault (TÛ) occurs in order to trigger automatic fault acknowledgement. The unit carries out internal fault acknowledgement after 3 seconds and is then ready again to accept drive commands.

The cause of the fault is shown on the display if the unit is in lock mode. The fault signal can be acknowledged by applying a signal (+24V) to an appropriately configured digital input (see **Section 5.7.3.2**) or by pressing "E". The unit does not have to be switched off.

Independent from the settings described, every error is recorded by the error stack.

5.7.8.7 Selection of works-setting

Extended
Works setting

In this menu you can call up the works-setting of the device by entering a 1 at menu-item "load". For storing this parameters, the item "copy" must be chosen.

Works setting
Load (1) 0

Attention, by doing this operation, all parameter-settings are overwritten !

Works setting
Copy

5.7.8.8 Configuration of inputs and outputs

Extended
Inputs/outputs

In this menu, you can configure the inputs and outputs of the unit.

5.7.8.9 Encoder

Inputs/outputs
Encoder input

Filtration of the encoder signal can be set here. This enables faulty sensor signals to be smoothened.

Encoder input
T-1 0

Note : A high filtration degree (e.g. T filter = 4) can lead to a worsening of control behaviour and cause vibrations on systems susceptible to vibration

Encoder input
normally

Here you can revise the rotational sense assignment of the encoder signals. The same effect can be achieved by exchanging wires A and B or -A and -B at the converter terminals.

Encoder input
inverted

Note : In case synchronous machines are used (**see Section 5.8.2**) this parameter is determined automatically and must not be changed for this reason !

5.7.8.10 Digital inputs

Inputs/outputs
Digin 1

Here, you can configure the 2 digital inputs of the converter:

Digin 1
Error Ack. (0)

Functionality of **digital input 1**:

Digin 1
Contact. Mon. (1)

"External fault acknowledgement input" function. A fault can be acknowledged by an external +24V signal on this input.

"Monitoring drive contactors" function. This function is only required in combination with our converter with integrated contactors. The drive contactors are checked for a drop at a standstill (500 msec after opening the ZS relay) via auxiliary contacts.

Inputs/outputs
Digin 2

Functionality of **digital input 2**:
(see digital input 1)

5.7.8.11 Drive Commands

5.7.8.11.1 Encoding

Drive Commands
Parallel

Here, you can select between parallel and binary encoding of the drive commands

Drive Commands
Parallel

Parallel encoding (standard).

Drive Commands
Binary

Binary encoding.

For binary encoding of the drive commands, controller inputs V1, V2, V3, V4 are used. The assignment is as follows:

Drive Speed VVVF	term. 16 (V1)	term. 17 (V2)	term. 18 (V3)	term.18 (V4)	remark
STOP	0	0	0	0	
V0	1	0	0	0	creep speed
V1	0	1	0	0	inspection
V1	1	1	0	0	Inspection
VN	0	0	1	0	fine levelling
V0	1	0	1	0	creep speed
V2	0	1	1	0	1 st intermediate speed
V2	1	1	1	0	1 st intermediate speed
V2	0	0	0	1	1 st intermediate speed
V3	1	0	0	1	2 nd intermediate speed
V4	0	1	0	1	high speed

5.7.8.11.2 Configuration of direction signals

Drive Commands
OnlyRO1) 0

Here, the VVVF controller can be configured for operation with only one direction signal. To do this, the parameter must be set to 1.

5.7.8.12 Further supervisions

Extended
Monitorings

Watchdog timer. A watchdog timer can be activated with this, i.e. the unit switches off and the relevant fault signal is displayed if the set driving time is exceeded. The minimum running time is 20 sec.; at smaller values, the watchdog timer is deactivated and 0 is displayed.

Monitors
Run-Time 0

Monitors
Contactor 0

The **monitoring function of the drive contactors** is activated here insofar as an appropriate digital input has been configured with this function (see **Section 5.7.8.10**).

5.7.8.13 Operating with DCP-Interface



5.7.8.13.1 General information on DCP operation

The DCP protocol is an RS-485 protocol designed specifically for elevator applications for data exchange between the control system and frequency converter and is already being used in practice and serves as a replacement for parallel control via the drive command terminals. This telegram does not only enable a drive and position control but also remote control of the converter from the control system.

5.7.8.13.2 Operating modes

The type of operating mode is shown on the control display. The appropriate operating mode is recognised from the incoming telegram and activated automatically.

5.7.8.13.2.1 DCP01 und DCP03 - Drive without pre-set braking distance

This operating mode is chosen most frequently because it represents the normal operating mode by shaft switch.

5.7.8.13.2.2 DCP02 - Drive with pre-set braking distance

The control system determines the braking distance to be covered for the converter.

5.7.8.13.3 Wiring

The converter terminals 67 (RS485-A) and 68 (RS485-B) must be connected with the respective control terminals. Furthermore, on the converter, connecting terminals 67 and 33 must be connected and terminals 68 and 32 must be connected (wire bridges) in order to enable half-duplex operation. A screened twisted-pair cable is recommended for the connection of the control and converter in series. The fault signal relay TÜ and the relay for the main contactor ZS should be wired as before. The relay ZB for the mechanical brake is replaced by a control bit in the telegram and therefore does not have to be wired.

The signal GS still has to be connected to terminal 53 for safety reasons. The auxiliary contacts of the drive contactors can be used to generate the signal insofar as these are activated direct from the control system upon starting.

5.7.8.13.4 Activation of the serial converter control (DCP mode)


First the control source must be set to "DCP" to activate the DCP mode.




To do so, call up the menu "**Extended**" - "**DCP**" and scroll through the sub-menus using the cursor keys until you reach the menu section alongside.



Call up the parameter choice using the "**E**" key. The terminal control is set to standard here.



Using the cursor keys, you can choose the DCP-Mode. Confirm this by pressing the enter key "**E**".



The control source is now re-parameterised to DCP while the message "OK..." appears on the display. The unit must be switched off and then on again after about 30 seconds in order for this change to become effective. The converter now expects telegrams from the control system.

5.7.8.13.5 Connection monitoring

```
*** Error ***
DCP-Error
```

If no or defective telegrams are received during the travel operation, the VVVF-controller switches over to fault mode.

```
Command source
...Deact. DCP ?
```

Press the Enter key again to switch over to terminal control and deactivate DCP mode. Press "C" to quit.

5.7.8.13.6 Diagnostics menu

```
Diagnostics
Quality 1000%
```

Here, the connection quality is displayed [per mil].
 Example :
 1000% : error rate 0 per mil
 998 % : error rate 2 per mil (of 1000 telegrams, 2 are defective)

```
Failures
SE 0 CS 0 S7 0
```

Here, several telegram error counters are provided indicating the current telegram status.

```
Controlbyte
---
```

Here, the DCP control byte is displayed

```
DCP-transmit
00 00 00
```

telegrams the converter sends to the control system

```
DCP-receive
00 00 00 00 00
```

telegrams the converter receives from the control system.

```
DCP
brake-way 0mm
```

The braking distance is displayed here by the control system.

```
DCP
rest-way 0mm
```

The remaining distance which still has to be covered is displayed here.

```
Diagnose
Position 0
```

Here, the current stop position of the cabin in the well is indicated (only in DCP03 - is transmitted by the controller).

5.7.8.13.7 Setting the S- curve at DCP02

The following parameters can be set:

```
DCP
S-Curve 10
```

If the control-system is presetting the braking distance, you can set the shape of the deceleration ramp.
 S-curve = 0: strong deceleration, fast reach of the levelling position
 S-curve = 25: smooth deceleration, slow reach of the levelling position
Note: The suitable value range for this parameter is between 5 and 15. If you select a higher value, this may result in abrupt deceleration when the levelling position is reached, since too much distance is covered at the beginning due to the flat shape.

5.7.8.14 Extended Error menu

```
Extended
Failure
```

Here, you can read out details of certain errors. This menu will be needed only after consultation with us (via the telephone) and will not be explained in detail here.

5.7.8.15 Converter-specific settings

```
Extended
Converter
```

These parameters should only be changed after consultation with us (via the telephone).

```
Converter
SinBoard      0
```

Enabling of sine encoder evaluation unit.

```
Converter
f_PWM        15kHz
```

PWM frequency of converter

```
Converter
Adaption.     0
```

enabling/disabling the automatic current controller adaptation. If the adaptation is enabled, a current controller adaptation is carried out at the beginning of the first travel operation after a change of the motor parameters.

```
Converter
Max. Curr    200%
```

overload factor of VVVF-controller.

5.7.8.16 Loosening the cabin from the safety catch, travel at increased break-away torque

```
Converter
V1MaxRuck     0
```

If you enter 1 for the travel speed V1, a set value jump will be prescribed. As a result, a jerk-like torque will be built up and the cabin can be loosened from the safety catch more easily.

5.7.8.17 Trace/Debug

```
Extended
Trace/Debug
```

In this menu, you can record and display internal variables. This is done for test and analysis purposes and is not intended for the user.

5.8 Use with synchronous machines / gearless

Extended
Sync.machine

In this menu, you will find the parameters which are required for using the unit with synchronous machines.

5.8.1 Parameterization

5.8.1.1 Automatic setup by using pre-defined data records

Sync.machine
Gearless-Type

Here, you will find a list of gearless types whose complete parameter records are saved in the unit.

Gearless-Type
Schindler

Press the E-key to select the required manufacturer.

Schindler
PMS230-A1060

Use the arrow keys to scroll through the list.

Schindler
ok ...

Press the E-key to select a drive type.



Now all parameters are configured for operation.

5.8.1.2 Manual setting of the parameters

Sync.machine
I_MOT 32A

Rated motor current.

Sync.machine
U_MOT 400V

Rated motor voltage.

Sync.machine
Pole pair 2

Number of pole pairs of the motor.

Sync.machine
Encoder 1024

Number of encoder pulses, number of sine periods / revolution.

Sync.machine
RhoOffset 0

Angle offset between encoder zero point and electrical zero point of motor winding (360° correspond to 8192).

Note: This parameter is determined automatically by the unit during calibration (see below).

Synch.machine
Sine mode

Sine evaluation method, depending on encoder type. Press E-key to open the selection list:

Sine mode
ECN1313 EnDat

Use of ECN1313 absolute value encoder with EnDat interface from Heidenhain.

Sine mode
SinCos Ref

Sine/cosine with zero pulse. Referencing required after switching on the supply voltage.

Sine mode
SinCos

Sine/cosine encoder for use with asynchronous machines.

Sine mode
SinCos Inc

Incremental evaluation of sine/cosine encoder (for tests only).

```
Synch.machine
Rho_corr      0
```

Currently without function

```
Synch.machine
Einph.On      0
```

Activation of calibration (see **Section 5.8.2**)

5.8.2 Calibration - determination of angle offset

5.8.2.1 Use with absolute value encoder ECN1313 from Heidenhain

5.8.2.1.1 Calibration

To enable operation of the synchronous machine it is necessary to measure the angle offset between the encoder zero point and the electrical zero point of the motor winding (**calibration**).



Important note: The measurement must be carried out with free-rotating motor and without load (slag rope)!

The following steps must be carried out:

Activation of calibration:

```
Synch.machine
Einph.On      1
```

Measurement in menu extended-synchronous machine-calibration=1.
Definition of drive commands by means of restoring control

```
< Info >
Calibration active
```

Motor turns until the measurement is complete, the status of the measurement is displayed.

```
< Info >
Rem. drive comm.!
```

Now, cancel all drive commands.

```
< Info >
Rho: -3204
```

The measured angle offset is displayed
Save the result by pressing the "E" key. Press the "C" key to quit.

```
< Info >
Save ? ...
```



Now, the drive is ready for operation.

To check the function issue travel commands again. **The drive must rotate correctly.** The displayed current must be 0.

5.8.2.1.2 Checking the rotational sense assignment

Check if the sense of rotation complies with the command issued, i.e. if the motor turns **UP** when command **RO** is issued. If yes, the calibration is complete, if no, exchange 2 motor phases (e.g. U and V) and start the measurement again (see "**Calibration**").

5.8.2.2 Use with sin/cos encoders with zero pulse

Info
Referencing

Info
Calibration

The processes are the same as in the case of **calibration**. Before a calibration can be carried out, the **encoder zero point** must be found. The unit carries out this **referencing** operation automatically when travel commands are issued. As soon as the zero point is determined, calibration takes place.



Note : After switching on the supply voltage, the zero point of the encoder must always be determined before the first travel operation. The search for the zero point is carried out automatically by the converter as soon as travel commands are issued, i.e. the elevator control system "does not know what's going on". Until the encoder zero pulse is found, the system runs **uncontrolled at rated motor current**. Then, the travel operation is continued with speed control without interruption. In the case of gearless drives the elevator may cover a distance of several meters until the zero pulse is reached! For this reason, these encoders should not be used with gearless drives.

5.9 Open-Loop Mode



Note:

- Operation without encoder feedback can result in increased heating of the motor and a worse travel behaviour than in the case of an operation with field-oriented vector control.
- Due to the different operating principle, the stopping accuracy in the case of U/F operation will always be slightly worse than in the case of operation with field-oriented vector control.
- In open-loop mode, the maximum traveling speed is 1 m/s.

5.9.1 Open-Loop 1 (F/U control with slip compensation)

5.9.1.1 Parameter overview

The setup menu comprises the following parameters:

Open-Loop 1
TADJ_TRM 80

Adaptation of motor rotor time constants.

Open-Loop 1
SlipKorr 8000

Slip reduction in the case of low speeds.

Open-Loop 1
MV 100%

Torque pre-control during acceleration and deceleration.

Open-Loop 1
LV 500%

Preset load for load equilibrium: A basic torque is preset when the brake is opened (static load compensation).

Open-Loop 1
U_Start 3000

Start voltage (automatic setting).

Open-Loop 1
Rl_Motor 700

Stator resistance of one motor winding (automatic setting).

Open-Loop 1
RlMessEn 0

Activation of automatic motor measurement.

5.9.1.2 Setup of converter

5.9.1.2.1 Activating the operating mode

First, the converter must be set to the appropriate operating mode. For this, open the system-operating mode menu.

```
System
Operating Mode
```

```
Operating mode
Open-Loop 1
```

Select the operating mode **Open Loop 1**.

5.9.1.2.2 Automatic measurement of motor parameters

The unit carries out a measurement of the motor characteristic and adjusts the corresponding parameters for the motor control automatically. In this operating mode you can measure the motor parameters once or during each travel operation.



To ensure an error-free measurement, the system data must be entered correctly (see **Section 5.5**) !

```
Extended
Open Loop
```

```
Open-Loop
Open-Loop 1
```

```
Open-Loop 1
R1MessEn      1
```

Go to menu *Extended - Open Loop - Open Loop 1*. Use the E-key to open the menu. Select parameter *R1MessEn*.

Enter "1" to activate the measurement.

Issue travel command. After switching on the output stage the unit will determine the stator resistance and the required starting voltage of the motor within a few milliseconds.

```
Open-Loop 1
R1MessEn      0
```

Then, the travel operation is carried out and the parameter *R1MessEn* is set to 0.

Note :

Normally, it is sufficient to measure the motor parameters once during commissioning. However, if the travel behaviour worsens significantly if the motor gets hotter, this is due to the fact that the motor parameters depend on the temperature.

```
Open-Loop 1
R1MessEn      2
```

In this case you can activate a permanent measurement by entering "2". Now, the unit will carry out a measurement upon each start. In this way, motor parameter changes which are due to an increased motor temperature are considered.

Carry out travel operation in both directions.

5.9.1.2.3 Setup of dynamics

During the measurement, the unit has adjusted all relevant parameters such that the motor current and voltage are sufficient for travel curves in elevator applications.

```
Open-Loop 1
MV          300 %
```

If, in the case of very dynamic acceleration ramps, the actual value does not follow the required value properly during acceleration, the parameter **MV** must be increased.

5.9.1.2.4 Adjusting the speed accuracy

Runing down
1300 rpm 23 A

The motor speed should be checked with a hand-held speed counter. The actual value must be compared to the set value which can be shown on the display. **To check the speed, high speed should be activated for several seconds since the unit compensates the slip and adjusts the speed accordingly during constant-speed travel.** If no speed counter is available, the duration of the creep speed up/down indicates if the travel speed is the same in both directions (braking distances must of course be the same in both directions).

Open-Loop 1
TADJ_TRM 80

In case the high speed empty down is too high, the parameter value **TADJ_TRM** must be reduced, if the speed is too low, it must be increased (in steps of 10-20).

Open-Loop 1
SlipKorr 10000

With this parameter it is possible to adjust a slip correction in the case of low speeds. In this way, the accuracy of the landing speed and thus the stopping accuracy can be adjusted perfectly. However, a manual speed counter is required to measure the landing speed. This parameter should be changed in steps of 1000.

5.9.1.2.5 Static load compensation

Open-Loop 1
LV 500%

With this parameter, the initial torque upon releasing of the brake can be determined (static load compensation). The load compensation is entered in per cent (see **Section 5.7.4.4**).

5.9.2 Open-Loop 2 (F/U control with characteristic adjustment)

5.9.2.1 Parameter overview

The setup menu comprises the following parameters:

Open-Loop 2
TADJ_TRM 80

Adaptation of motor rotor time constants.

FU op.mode 2
MV 100%

Torque pre-control during acceleration and deceleration.

Open-Loop 2
LV 500%

Preset load for load equilibrium: A basic torque is preset when the brake is opened (static load compensation).

Open-Loop 2
Umot_Imy 7 %

Magnetization current of the motor (automatic setting).

Open-Loop 2
Umot_Iq 5 %

Acceleration current (automatic setting).

Open-Loop 2
UOffset 192

Voltage offset of converter (automatic setting).

Open-Loop 2
Rl_Motor 700

Stator resistance of one motor coil (automatic setting).

Open-Loop 2
RlMessEn 0

Activation of automatic motor measurement.

5.9.2.2 Setup of converter

5.9.2.2.1 Activating the operating mode

First, the converter must be set to the appropriate operating mode. For this, open the system-operating mode menu.

```
System
Operating Mode
```

```
Operating mode
Open-Loop 2
```

Select the operating mode **Open Loop 2**.

5.9.2.2.2 Automatic measurement of motor parameters

The unit carries out a measurement of the motor characteristic and adjusts the corresponding parameters for the motor control automatically.



To ensure an error-free measurement, the system data must be entered correctly (see **Section 5.5**) !

To measure the motor parameters, please adjust the control system to "restore" or "inspection".

```
Extended
Open Loop
```

```
Open-Loop
Open-Loop 2
```

```
Open-Loop 2
R1MessEn      1
```

Go to menu *Extended - Open Loop - Open Loop 2*. Use the E-key to open the menu. Select parameter *R1MessEn*.

Enter "1" to activate the measurement.

Enter a travel command via the feedback control system.

```
< Info >
motor adaptation
```

The travel contactors must pick up and the measurement is started. The duration of the measurement is approx. **5 seconds**.

```
Open-Loop 2
R1MessEn      0
```

After the measurement, the drive will start - cancel travel command. The parameter *R1MessEn* is set to 0.

Now, the unit has measured the stator resistance of the motor and the voltage offset of the converter and adjusted the optimum current vectors. The drive is ready for service now. The control system can be switched to normal mode again.

Carry out travel operation in both directions.

5.9.2.2.3 Setup of dynamics

During the measurement, the unit has adjusted all relevant parameters such that the motor current and voltage are sufficient for travel curves in elevator applications.

```
Open-Loop 2
MV          300 %
```

If, in the case of very dynamic acceleration ramps, the actual value does not follow the required value properly during acceleration, the parameter **MV** must be increased.

5.9.2.2.4 Adjusting the speed accuracy

Running down 1300 rpm 23 A

The motor speed should be checked with a hand-held speed counter. The actual value must be compared to the set value which can be shown on the display. If no speed counter is available, the duration of the creep speed up/down indicates if the travel speed is the same in both directions (braking distances must of course be the same in both directions).

Open-Loop 2 TADJ_TRM 80

In case the high speed is too high, the parameter value **TADJ_TRM** must be reduced, if the speed is too low, it must be increased.

5.9.2.2.5 Static load compensation

Open-Loop 2 LV 500%

With this parameter, the initial torque upon releasing of the brake can be determined (static load compensation). The load compensation is entered in per cent (see **Section 5.7.4.4**).


5.10 Emergency current evacuation with UPS

5.10.1 General

In the case of a power failure, it is possible with the VVVF controller to execute a travel operation at reduced speed. The maximum travel duration and speed primarily depend on the UPS used. The frequency converters are designed for using cost-efficient one-phase uninterruptible power supplies in evacuation mode. In this case, power is supplied directly at Phases L1 and L2; an expensive charging circuit for the intermediate circuit and battery management are not required.

5.10.2 Wiring

The following illustration shows the circuit diagram of an automatic switch-over to UPS mode as well as the return to mains mode. A phase monitoring relay type **PTW-3μP** which is available at RST Elektronik is used for monitoring the mains voltage.



Function:

In standard mode, the internal relay has picked up at terminals 11-12-14. Thus, mains contactor K14 is engaged, too. Since the two contactors K12 and K14 must not have picked up at the same time, they are interlocked in three ways: first via the internal change-over switch of the **PTW-3μP**, second through the interlock via the auxiliary normally-closed contacts and third via a pick-up delay of the contactors (approx. 3 to 5 s).

In the case of a mains failure, the internal phase monitoring relay and thus K14 drop out. After the time delay, K12 picks up and supplies the VVVF controller (one phase) from the UPS via the input phases L1 and L2. Via the auxiliary make contact of K12, the internal 24V supply voltage is applied to terminal 22 (Uniln1). In this way, the VVVF-controller is informed that emergency mode is activated. Low-voltage monitoring is deactivated for this operating mode.

If the mains supply is restored, **PTW-3μP** switches back to standard mode: K12 drops out and K14 picks up after a time delay.

Since the **PTW-3μP** is programmed such that a complete disconnection of all 3 phases does not trigger a fault, a failure of phases L2 and L3 would not be recognized. If, however, terminal "0" is connected to the neutral conductor, this operating status is taken into account, too. However, if L1 fails, the **PTW-3μP** has no supply voltage. In this case, too, the internal relay drops out as required. Indication of the operating status, however, is no longer possible.

5.10.3 Dimensioning of UPS

For determining the required apparent power of the UPS, the motor efficiency must be determined first using the information indicated on the type plate:

$$\eta_M = \frac{P_M}{\sqrt{3} \cdot U_M \cdot I_M \cdot \cos \varphi_M} \quad [1]$$

η_M	motor efficiency
P_M	rated motor power
U_M	rated motor voltage
I_M	rated motor current
$\cos \varphi_M$	displacement factor of motor

The apparent power of the UPS required for evacuation travel operations to the next floor at nominal load and 5 % of the nominal speed can be determined as follows:

$$S_{USV} \approx \left(\frac{1,2}{\eta_M} - 1,1 \right) \cdot P_M \quad [2]$$

S_{USV}	apparent power of UPS
P_M	Rated motor power at rated speed and nominal load
η_M	motor efficiency

The following requirements must be met:

- * The calculated motor efficiency is at least 75%.
- * Operation is effected with field-oriented control, i.e. no open-loop mode.
- * The output voltage of the UPS is at least 220 ~ even under load.
- * The crest factor (peak current/effective current ratio) of the UPS is at least 3:1 (caution: the peak current is not the effective start-up or acceleration current).
- * Other consumers such as controller, cabin lighting, well lighting, etc. must always be taken into account.
- * If a stop other than the nearest possible stop is to be approached, the bridging time of the UPS under full load must be greater than the time required for traveling through the well at evacuation speed.

5.10.4 Particularities of the VVVF-controller during evacuation

Through High level (+24V) at the digital input **Uniln1** (terminal 22), the VVVF-controller is informed that **evacuation mode** is active.

The VVV-controller has a digital output **DigOut3** (terminal 56) through which the load situation after opening of the brake are signaled.

- High level (+24V): cabin is heavier than counterweight. recommended direction = DOWN
- Low level (0V): cabin is lighter than counterweight. recommended direction = UP

Through an evaluation of this signal by the controller, the evacuation can be effected in the "easier" direction.

In evacuation mode, the following applies:

- Undervoltage monitoring of the intermediate circuit is suppressed.
- **Before the travel command is issued**, evacuation mode must be activated via **Uniln1**.
- Independent of the current travel commands, the operation is carried out at evacuation speed **VE**.
- To enable a travel operation, **Uniln1** and a „normal“ travel command (**V1, V2, V3, V4, VN**) must be present.
- The travel operation is continued as long as Uniln1 is active with a travel command. **A stop can be effected by withdrawing the Uniln1, the travel command or both signals.**

5.11 Remote data transmission per modem

5.11.1 General

With the new PowerControl software it is possible to carry out remote settings on the frequency converter via the telephone network (RDT- remote data transmission). Two modems are required for this.

The data communications connection is mainly used for "**remote monitoring**" (e.g. reading out the fault memory, operating parameters). With the modem connection, you have the same possibilities for settings and displays on the laptop/PC as if you were connected directly with the unit.



Note : Certain parameters (system data, delay routes) should only be changed per data communications when an engineer is on site at the system.

5.11.2 Modem on laptop/PC

The modem must be connected with the serial interface of the laptop/PC using a standard serial interface cable (1:1 connection) and plugged into the telephone network.

5.11.3 Modem on FRC-Q

The modem is connected to the telephone network via the external interface module and the serial interface of the converter.

Note : Only one unit may be connected to the converter interface at a time. A fault occurs if the modem and laptop are connected at the same time!

5.11.3.1 Configuration of modem on the converter

The configuration of the modem on the converter must be as follows:

Settings	Command*)	Important!
Echo: off	E0	NOTE! The modem must be capable of storing this data permanently.
Answer on DDE: off	Q1	
Pick-up after 1 st ring	S0=1	
DDE-speed: 9600/N/8/1	S23=58	
Disconnect after 15 sec. without carrier	S7=15	
save current configuration	&W0	
configuration upon switching on	&Y0	
*) command depending on type of modem used		

The modem can be configured to required settings using the PowerControl software (see PowerControl software manual).

We recommend buying a modem pre-configured by us.

6 Service and maintenance

Modern electronic components have a long service life and are not subject to mechanical wear and tear. Therefore, the VVVF controller normally needs no maintenance.

Within the range of the standard elevator maintenance, however, check the connectors for tight fit and contacts of the output relays with regard to arc erosion.

At elevators in contaminated environments (chemical and similar industries), it may be necessary to blow off dust and dirt from the printed circuit boards and power components in order to avoid creepage current and flashover.

Also it might be necessary to remove dust from the ribs of the heat sink. In office and residential buildings, however, this is normally not necessary.

Encoders which are not directly flanged to the machine or integrated in it, but only indirectly connected to the motor shaft by a driving belt (in most cases toothed belts), regularly need to be checked with regard to sufficient belt tension.

7 FRC-Q with integrated drive contactors

7.1 General

The frequency converter can also be supplied with integrated drive contactors. The drive contactors correspond to utilisation category AC3 and are fitted with auxiliary contactors. The unit can also be ordered with further components. Internal wiring in compliance with customer specifications.

A **Plug & Play system** is being offered where the frequency converter is just plugged into the control system. This avoids any possibility of wiring mistakes on site. Until now, the interface between the elevator control and the VVVF is realized with nearly all control-manufacturers.

The complete unit is enclosed in a housing so that it can be fastened to a wall outside the enclosure. **The braking resistance is integrated in the unit up to size 6.**



Warning: Due to the heat dissipation of the brake resistor the unit should always be fixed on an inflammable base (e.g. concrete wall). For proper ventilation of the braking resistance there should be at least 20cm space above and below the unit.

If there are inflammable materials in the closer area, there should be a distance of 50cm between the unit and these materials.

7.2 Technical Specification

The currents correspond to that of the standard unit.

housing	Dimensions		
	Width	Height	Depth
FRC-F1...F6	400 mm	725 mm	275 mm
FRC-F7	400 mm	864 mm	275 mm

7.2.1 Housing

7.2.2 Fastening the cables

The cable inlet is through the lower opening. On standard designs, the cable fastening plate is located on the underside of the unit's mounting plate.

The cable fastening plate provides strain relief for the cables and screens the cables. Connect the cables as follows:

unshielded cables:

- Fasten with provided cable binders in the holes in the middle of the panel.

shielded cables:

- Uncover cable shield.
- Select appropriate cable clip.
- Insert provided plate nuts at required points so that the smooth surface is facing upwards.
- Using provided M4 screws, fasten clip in place in the plate nuts.

The sensor cable is also fed into the housing from below, through the opening with the split cable bush to the plug-in terminals and fastened to the cable fastening plate using a cable clip.

The cable routing for any connected motor PTC thermistor is exactly the same as for the sensor cable, but in this case it is fastened using a cable binder.

7.2.3 Wiring

The mains supply line is connected to the terminals "*L1-L2-L3-PE*". On units with integrated miniature circuit breakers, the neutral wire must be connected to the terminal marked in blue.

The brake resistor lead is connected to the terminals "*RB*" and "*+*" and "*PE*". In the case of units with integrated braking resistance, no external wiring is required.

The motor lead is connected direct to the contacts marked "*U-V-W*" and the PE terminal.

The control cable is just plugged into the control system on ***Plug&Play units***.

8 Troubleshooting

Note : The following compilation covers the most common errors and warnings.

8.1 Error messages at the converter

8.1.1 Encoder polarity

Triggered:

Signs of set and actual value do not correspond.

Causes and remedy:

Assignment of motor sense of rotation and incremental encoder tracks is not correct. During up-movement of the cabin, a positive speed must be displayed.

Exchange pulse encoder track A and B or -A and -B or 2 motor phases.

8.1.2 No start-up

Triggered:

Despite set value and 100 % torque, not actual movement recognized.

Causes and remedy:

The incremental encoder is not connected properly or is defective Check if a speed is displayed when the cabin is moving.

The encoder pulses of the incremental encoder are parameterized incorrectly.

The brake does not open, i.e. motor is overloaded.

The motor produces too little torque because the converter was not adjusted to the motor correctly.

8.1.3 Overspeed

Triggered:

Actual speed is higher than $V4 + 20\%$

Causes and remedy:

Uncontrolled opening of the brake without converter activity.

Opening of traveling contactors during a travel operation.

Tachometer defective or fault signal injection on the tachometer lead .

8.1.4 Control Deviation

Triggered:

The deviation between the set and actual value is greater than 20 % of $V4$ for 3 seconds.

Causes and remedy:

Motor not adjusted to the converter correctly.

Motor overloaded.

Converter too small.

Compare system data with motor type plate.

8.1.5 Overcurrent

Triggered:

Current value exceeds the maximum converter current.

Causes and remedy:

Short-circuit in the converter output circuit, e.g. due to motor damage or wrong wiring.

Check wiring

Measure motor.

8.1.6 Overvoltage DC

Here, it has to be assumed that the power in the brake operation can no longer be fed from the DC-link. Possibly the braking resistor is connected incorrectly or defective.
Increased mains voltage can also cause this error.

8.1.7 Undervoltage DC

Triggered:
DC-link voltage falls below a certain value.

Causes and remedy:

Too low mains voltage (e.g. emergency power operation in the case of generator overload, temporary (construction) power supply with small supply cable cross-section, mains voltage reductions
areas with "soft network").

8.1.8 Motor adaptation

Triggered
An error occurred during current controller setup.
Motor-converter connection interrupted.

Causes and remedy:

Travel contactors not picked up.
Contacts of travel contactors worn out.
Wiring error.

8.1.9 Temperature KK. (Overtemperature)

Triggered
Temperature increases above a limit.

Causes and remedy:

Too high ambient temperature.
No ventilation opening in the enclosure.
Converter too small.

8.1.10 DCP error

Triggered:
Defective or no telegrams from control system

Causes and remedy:

DCP connection cable twisted and shielded ?
Shields connected to PE properly ?

Switching of the travel contactors under current.

8.1.11 Runtime error

Triggered:
The programmed runtime monitor has responded.

Causes and remedy:

Deactivate runtime monitor or increase time.

8.1.12 Contactors error

Triggered:
Travel contactors still picked up 0.5 seconds after the ZS relay was switched off

Causes and remedy:

Check if the contactors are still activated after 0.5 seconds after switching off the ZS relay.

8.1.13 Power unit

Triggered:

The error message is generated by the power modules of the converter.

Causes and remedy:

High EMC impact.

Converter defective

Check shields and RC-elements of contactors.

Check if large interference sources (e.g. large machines, ...) are located near the converter.

Replace converter.

8.1.14 Calibration

Causes and remedy:

An error has occurred during the calibration of the synchronous machine.

Consult RST.

8.1.15 Earth fault

Triggered:

The measured earth fault current exceeds the permissible value.

Causes and remedy:

High EMC impact.

Motor defective.

Check shields and RC-elements of contactors.

Check if large interference sources (e.g. large machines, ...) are located near the converter.

Measure motor.

8.1.16 Motor overload

Triggered:

The load limit of the motor was exceeded.

Causes and remedy:

Wrong parameterisation.

Incremental encoder defective.

Motor possibly too small.

Check parameterisation.

Consult RST.

8.1.17 Phase failure

Triggered:

The phase monitor has responded.

Causes and remedy:

Mains voltage too low.

Mains phase failure.

Check mains supply.

8.1.18 Referencing

Triggered:

The encoder zero pulse was not found.

Causes and remedy:

Wrong parameterisation (menu synchronous machine - sinmode).

Wiring error.

sine encoder defective.
Consult RST.

8.1.19 SSC Error

Triggered:
Defective internal telegrams.

Causes and remedy:
Printed circuit board defect.

Remedy:
Replace circuit board or converter

8.1.20 Sine controller

Triggered:
The sine evaluation unit detected an error.

Causes and remedy:
Parameterised number of pulses of ECN1313 encoder does not correspond to the actual number of pulses.
Amplitudes of sine signals are outside of permissible range.
Check sine encoder wiring.

8.2 Warnings at converter

8.2.1 Direction signals

A change of the direction signals at speed > 25 rpm was detected. This warning can occur in particular in inspection mode. For safety reasons the unit ignores a change of direction above a minimum speed of 25 rpm.

8.2.2 Temperature

The cooling body temperature has exceeded the pre-warning limit.

8.2.3 Motor data o.k. ?

No slip was considered when setting the system data parameters. Possibly, the synchronous speed (e.g. 1500) was parameterised instead of the rated speed (e.g. 1450) (see **Section 5.5**).

8.2.4 Version PowerCtr

The device has recognized that the setting software on your PC is not compatible with the controller software. Parameter modifications with the PC are not possible. However, the drive-curves can be displayed and stored on your PC.